

WEBVTT

NOTE duration: "00:29:00.160"

NOTE Confidence: 0.9443829

00:00:00.160 --> 00:00:01.920 Funding for Yale Cancer Answers

NOTE Confidence: 0.9443829

00:00:01.920 --> 00:00:03.679 is provided by Smilow Cancer

NOTE Confidence: 0.9443829

00:00:03.679 --> 00:00:04.180 Hospital.

NOTE Confidence: 0.9631407

00:00:06.160 --> 00:00:08.080 Welcome to Yale Cancer Answers

NOTE Confidence: 0.9631407

00:00:08.080 --> 00:00:09.119 with the director of the

NOTE Confidence: 0.9631407

00:00:09.119 --> 00:00:10.800 Yale Cancer Center, doctor Eric

NOTE Confidence: 0.9631407

00:00:10.800 --> 00:00:11.300 Weiner.

NOTE Confidence: 0.9832591

00:00:11.840 --> 00:00:14.019 Yale Cancer Answers features conversations

NOTE Confidence: 0.9832591

00:00:14.240 --> 00:00:15.965 with on ologists and specialists

NOTE Confidence: 0.9832591

00:00:15.965 --> 00:00:17.005 who are on the forefront

NOTE Confidence: 0.9832591

00:00:17.005 --> 00:00:17.965 of the battle to fight

NOTE Confidence: 0.9832591

00:00:17.965 --> 00:00:18.465 cancer.

NOTE Confidence: 0.9665273

00:00:19.085 --> 00:00:20.305 This week, it's a conversation

NOTE Confidence: 0.9665273

00:00:20.445 --> 00:00:22.605 about radiation oncology with doctor

NOTE Confidence: 0.9665273

00:00:22.605 --> 00:00:23.425 Peter Glaser.
NOTE Confidence: 0.95460856

00:00:23.885 --> 00:00:25.244 Doctor Glaser is the Robert
NOTE Confidence: 0.95460856

00:00:25.244 --> 00:00:26.945 E. Hunter Professor of Therapeutic
NOTE Confidence: 0.95460856

00:00:27.165 --> 00:00:27.665 Radiology
NOTE Confidence: 0.96996987

00:00:28.205 --> 00:00:30.160 and Professor of Genetics and
NOTE Confidence: 0.96996987

00:00:30.160 --> 00:00:31.280 chair of the department of
NOTE Confidence: 0.96996987

00:00:31.280 --> 00:00:33.120 therapeutic radiology at the Yale
NOTE Confidence: 0.96996987

00:00:33.120 --> 00:00:34.020 School of Medicine.
NOTE Confidence: 0.8627474

00:00:34.560 --> 00:00:35.700 Here's doctor Wiener.
NOTE Confidence: 0.96742463

00:00:36.720 --> 00:00:38.400 Can you just tell us
NOTE Confidence: 0.96742463

00:00:38.400 --> 00:00:40.020 a little bit about you?
NOTE Confidence: 0.96742463

00:00:40.159 --> 00:00:41.680 You know, how is it
NOTE Confidence: 0.96742463

00:00:41.680 --> 00:00:43.140 that you came to become
NOTE Confidence: 0.96742463

00:00:43.200 --> 00:00:44.500 a radiation oncologist?
NOTE Confidence: 0.92239887

00:00:45.425 --> 00:00:46.545 Yeah, so so I'm a
NOTE Confidence: 0.92239887

00:00:46.545 --> 00:00:48.704 physician scientist with an MD

NOTE Confidence: 0.92239887
00:00:48.704 --> 00:00:50.165 and a PhD in genetics,
NOTE Confidence: 0.91968155
00:00:50.625 --> 00:00:51.604 and as you mentioned,
NOTE Confidence: 0.90205747
00:00:51.985 --> 00:00:53.425 my medical specialty is in
NOTE Confidence: 0.90205747
00:00:53.425 --> 00:00:54.485 radiation oncology.
NOTE Confidence: 0.7139904
00:00:55.265 --> 00:00:55.665 And,
NOTE Confidence: 0.9828321
00:00:56.145 --> 00:00:58.245 my research focuses on fundamental
NOTE Confidence: 0.9828321
00:00:58.305 --> 00:00:59.765 cancer biology and
NOTE Confidence: 0.9238002
00:01:00.580 --> 00:01:01.960 development of translational
NOTE Confidence: 0.9945344
00:01:02.260 --> 00:01:03.240 research opportunities.
NOTE Confidence: 0.8578452
00:01:04.420 --> 00:01:04.900 So,
NOTE Confidence: 0.9872965
00:01:05.459 --> 00:01:06.580 I got started in the
NOTE Confidence: 0.9872965
00:01:06.580 --> 00:01:08.100 field because of a strong
NOTE Confidence: 0.9872965
00:01:08.100 --> 00:01:09.640 clinical interest in oncology,
NOTE Confidence: 0.9546375
00:01:10.660 --> 00:01:11.620 and in taking care of
NOTE Confidence: 0.9546375
00:01:11.620 --> 00:01:13.140 cancer patients, and that was
NOTE Confidence: 0.9546375

00:01:13.140 --> 00:01:15.155 coupled with a growing research

NOTE Confidence: 0.9546375

00:01:15.215 --> 00:01:16.655 interest in the field of

NOTE Confidence: 0.9546375

00:01:16.655 --> 00:01:18.415 DNA repair, which is how

NOTE Confidence: 0.9546375

00:01:18.415 --> 00:01:19.795 cells fix their DNA.

NOTE Confidence: 0.9982176

00:01:20.655 --> 00:01:22.255 And that's an important topic

NOTE Confidence: 0.9982176

00:01:22.255 --> 00:01:23.395 in the field of radiation

NOTE Confidence: 0.9982176

00:01:23.455 --> 00:01:23.955 oncology.

NOTE Confidence: 0.99171865

00:01:25.135 --> 00:01:26.550 And can you just

NOTE Confidence: 0.9995375

00:01:27.110 --> 00:01:28.569 tell us a little bit

NOTE Confidence: 0.9995375

00:01:28.630 --> 00:01:29.130 about

NOTE Confidence: 0.9548489

00:01:29.670 --> 00:01:31.290 radiation as a treatment,

NOTE Confidence: 0.9984775

00:01:32.870 --> 00:01:34.390 both in terms of how

NOTE Confidence: 0.9984775

00:01:34.390 --> 00:01:35.290 it's delivered

NOTE Confidence: 0.7605047

00:01:35.910 --> 00:01:36.410 or

NOTE Confidence: 0.955898

00:01:36.790 --> 00:01:38.870 I should say the different

NOTE Confidence: 0.955898

00:01:38.870 --> 00:01:39.990 ways in which it can

NOTE Confidence: 0.955898
00:01:39.990 --> 00:01:40.650 be delivered.
NOTE Confidence: 0.9922816
00:01:41.685 --> 00:01:43.524 And then we'll we'll explore
NOTE Confidence: 0.9922816
00:01:43.524 --> 00:01:45.145 some other aspects of radiation.
NOTE Confidence: 0.98677063
00:01:45.604 --> 00:01:47.125 Sure. So, you know, radiation
NOTE Confidence: 0.98677063
00:01:47.125 --> 00:01:49.384 oncology is the medical specialty
NOTE Confidence: 0.9847176
00:01:49.844 --> 00:01:51.444 that uses focused x rays
NOTE Confidence: 0.9847176
00:01:51.444 --> 00:01:52.424 to treat cancer
NOTE Confidence: 0.98173666
00:01:52.804 --> 00:01:53.924 because of their ability to
NOTE Confidence: 0.98173666
00:01:53.924 --> 00:01:55.145 kill cancer cells.
NOTE Confidence: 0.978166
00:01:55.820 --> 00:01:57.580 And early medical applications of
NOTE Confidence: 0.978166
00:01:57.580 --> 00:01:59.440 radiation were based on radioactive
NOTE Confidence: 0.978166
00:01:59.740 --> 00:02:01.040 materials like radium
NOTE Confidence: 0.96877635
00:02:01.420 --> 00:02:02.800 that were discovered by
NOTE Confidence: 0.9524626
00:02:03.260 --> 00:02:05.260 Marie Curie, because early on
NOTE Confidence: 0.9524626
00:02:05.260 --> 00:02:06.300 it was found that radiation
NOTE Confidence: 0.9524626

00:02:06.300 --> 00:02:07.840 causes tumors to shrink.
NOTE Confidence: 0.9160222

00:02:08.715 --> 00:02:10.395 Later on other isotopes like
NOTE Confidence: 0.9160222

00:02:10.395 --> 00:02:11.535 cobalt, iridium,
NOTE Confidence: 0.9465155

00:02:12.235 --> 00:02:14.235 and others were identified and
NOTE Confidence: 0.9465155

00:02:14.235 --> 00:02:14.735 developed,
NOTE Confidence: 0.97021955

00:02:15.115 --> 00:02:15.995 and some are used for
NOTE Confidence: 0.97021955

00:02:15.995 --> 00:02:17.195 a type of treatment called
NOTE Confidence: 0.97021955

00:02:17.195 --> 00:02:19.435 brachytherapy, which involves placement of
NOTE Confidence: 0.97021955

00:02:19.435 --> 00:02:19.935 radioactive
NOTE Confidence: 0.9963696

00:02:20.235 --> 00:02:20.735 sources
NOTE Confidence: 0.97224194

00:02:21.659 --> 00:02:23.099 in close proximity to a
NOTE Confidence: 0.97224194

00:02:23.099 --> 00:02:24.939 tumor as is frequently done
NOTE Confidence: 0.97224194

00:02:24.939 --> 00:02:26.079 for, cancers
NOTE Confidence: 0.9463243

00:02:26.780 --> 00:02:27.099 of,
NOTE Confidence: 0.94250464

00:02:27.739 --> 00:02:28.400 the gynecologic,
NOTE Confidence: 0.8802894

00:02:29.819 --> 00:02:30.959 tract in women.

NOTE Confidence: 0.95679003

00:02:31.340 --> 00:02:33.180 So a device is actually

NOTE Confidence: 0.95679003

00:02:33.180 --> 00:02:34.379 put in and it gives

NOTE Confidence: 0.95679003

00:02:34.379 --> 00:02:35.120 off radiation

NOTE Confidence: 0.9969416

00:02:35.419 --> 00:02:36.719 while it sits

NOTE Confidence: 0.9623813

00:02:37.315 --> 00:02:39.475 essentially near or within somebody.

NOTE Confidence: 0.9623813

00:02:39.475 --> 00:02:40.995 That's right. It dwells in,

NOTE Confidence: 0.9623813

00:02:41.315 --> 00:02:42.194 in in the,

NOTE Confidence: 0.9784024

00:02:43.155 --> 00:02:44.215 next to the tumor.

NOTE Confidence: 0.9412079

00:02:44.755 --> 00:02:46.355 It's put in in a

NOTE Confidence: 0.9412079

00:02:46.355 --> 00:02:48.035 surgical procedure, and then it's

NOTE Confidence: 0.9412079

00:02:48.035 --> 00:02:49.919 removed after a specified time.

NOTE Confidence: 0.91906005

00:02:51.280 --> 00:02:52.639 And then some other in

NOTE Confidence: 0.91906005

00:02:52.639 --> 00:02:54.720 some other approaches, isotopes are

NOTE Confidence: 0.91906005

00:02:54.720 --> 00:02:57.139 injected systemically for special applications

NOTE Confidence: 0.93126523

00:02:57.840 --> 00:02:59.200 usually linked to a carrier

NOTE Confidence: 0.93126523

00:02:59.200 --> 00:03:00.099 like an antibody.
NOTE Confidence: 0.8610881

00:03:00.959 --> 00:03:02.180 So, you know,
NOTE Confidence: 0.9497798

00:03:02.480 --> 00:03:03.840 when X rays were first
NOTE Confidence: 0.9497798

00:03:03.840 --> 00:03:05.025 developed, it was known that
NOTE Confidence: 0.9497798

00:03:05.025 --> 00:03:06.224 they could be generated by
NOTE Confidence: 0.9497798

00:03:06.224 --> 00:03:07.665 cathode ray tubes, but but
NOTE Confidence: 0.9497798

00:03:07.665 --> 00:03:08.784 that was low energy and
NOTE Confidence: 0.9497798

00:03:08.784 --> 00:03:10.864 had drawbacks. So after World
NOTE Confidence: 0.9497798

00:03:10.864 --> 00:03:12.325 War II, a major advance
NOTE Confidence: 0.9497798

00:03:12.385 --> 00:03:14.165 was the development of technology
NOTE Confidence: 0.9497798

00:03:14.385 --> 00:03:14.885 to
NOTE Confidence: 0.90001875

00:03:15.264 --> 00:03:16.484 accelerate electrons,
NOTE Confidence: 0.9869084

00:03:17.510 --> 00:03:18.870 at high voltage into a
NOTE Confidence: 0.9869084

00:03:18.870 --> 00:03:20.250 medical target to
NOTE Confidence: 0.9133087

00:03:20.630 --> 00:03:22.150 generate high energy x rays
NOTE Confidence: 0.9133087

00:03:22.150 --> 00:03:22.889 or photons.

NOTE Confidence: 0.8574264

00:03:23.270 --> 00:03:24.389 And that was the birth

NOTE Confidence: 0.8574264

00:03:24.389 --> 00:03:26.389 of the linear accelerator or

NOTE Confidence: 0.8574264

00:03:26.389 --> 00:03:26.889 LINAC.

NOTE Confidence: 0.9344603

00:03:27.510 --> 00:03:29.270 And this allowed for treatment

NOTE Confidence: 0.9344603

00:03:29.270 --> 00:03:30.470 of deep seated tumors in

NOTE Confidence: 0.9344603

00:03:30.470 --> 00:03:31.995 the body with sparing of

NOTE Confidence: 0.9344603

00:03:32.155 --> 00:03:32.655 superficial

NOTE Confidence: 0.9975171

00:03:32.955 --> 00:03:33.455 tissues.

NOTE Confidence: 0.9509312

00:03:33.915 --> 00:03:34.415 And

NOTE Confidence: 0.99436325

00:03:35.034 --> 00:03:35.995 it seems to me that

NOTE Confidence: 0.99436325

00:03:35.995 --> 00:03:37.355 it was the case many

NOTE Confidence: 0.99436325

00:03:37.355 --> 00:03:38.174 years ago

NOTE Confidence: 0.8869544

00:03:38.715 --> 00:03:41.055 that radiation oncologists would take

NOTE Confidence: 0.8869544

00:03:41.114 --> 00:03:42.575 an x-ray and x-ray,

NOTE Confidence: 0.9856625

00:03:42.955 --> 00:03:44.555 just a standard x-ray that

NOTE Confidence: 0.9856625

00:03:44.555 --> 00:03:46.075 might show, for example, in
NOTE Confidence: 0.9856625

00:03:46.075 --> 00:03:46.735 the chest
NOTE Confidence: 0.95888144

00:03:47.270 --> 00:03:48.170 a lung cancer.
NOTE Confidence: 0.9985215

00:03:48.870 --> 00:03:49.370 And
NOTE Confidence: 0.9949631

00:03:49.910 --> 00:03:51.750 in what now seems like
NOTE Confidence: 0.9949631

00:03:51.750 --> 00:03:53.690 a pretty crude manner,
NOTE Confidence: 0.9951218

00:03:54.069 --> 00:03:56.069 they would just draw around
NOTE Confidence: 0.9951218

00:03:56.069 --> 00:03:57.830 that tumor and then aim
NOTE Confidence: 0.9951218

00:03:57.830 --> 00:03:58.569 the beam
NOTE Confidence: 0.9978577

00:03:59.834 --> 00:04:01.375 at the tumor. Is that
NOTE Confidence: 0.99432415

00:04:02.075 --> 00:04:03.614 basically right? Yeah.
NOTE Confidence: 0.8962092

00:04:03.995 --> 00:04:04.735 Early on,
NOTE Confidence: 0.9709413

00:04:05.355 --> 00:04:07.515 the the treatment machines were
NOTE Confidence: 0.9709413

00:04:07.515 --> 00:04:09.114 were limited in in,
NOTE Confidence: 0.9943869

00:04:09.754 --> 00:04:11.194 their ability to move and
NOTE Confidence: 0.9943869

00:04:11.194 --> 00:04:13.534 to deliver shaped beams. So

NOTE Confidence: 0.9943869
00:04:13.750 --> 00:04:15.030 most of the treatments were
NOTE Confidence: 0.9943869
00:04:15.030 --> 00:04:15.910 from the front or the
NOTE Confidence: 0.9943869
00:04:15.910 --> 00:04:17.110 back of the patient in
NOTE Confidence: 0.9943869
00:04:17.110 --> 00:04:17.770 a simple
NOTE Confidence: 0.89462936
00:04:18.150 --> 00:04:18.650 way.
NOTE Confidence: 0.95531887
00:04:19.669 --> 00:04:21.110 And so we were guided
NOTE Confidence: 0.95531887
00:04:21.110 --> 00:04:22.470 by what we kind of
NOTE Confidence: 0.95531887
00:04:22.470 --> 00:04:23.850 refer to as two dimensional
NOTE Confidence: 0.95531887
00:04:23.910 --> 00:04:25.430 imaging, which is those plain
NOTE Confidence: 0.95531887
00:04:25.430 --> 00:04:26.490 film x rays.
NOTE Confidence: 0.96178615
00:04:27.029 --> 00:04:28.150 But, you know, one of
NOTE Confidence: 0.96178615
00:04:28.150 --> 00:04:29.130 the major advances,
NOTE Confidence: 0.97297657
00:04:30.015 --> 00:04:31.695 in in the field has
NOTE Confidence: 0.97297657
00:04:31.695 --> 00:04:32.995 been the use of advanced
NOTE Confidence: 0.97297657
00:04:33.055 --> 00:04:35.375 imaging like CT scans, MRI
NOTE Confidence: 0.97297657

00:04:35.375 --> 00:04:36.654 scans, or now even PET
NOTE Confidence: 0.97297657

00:04:36.654 --> 00:04:37.154 scanning
NOTE Confidence: 0.94852924

00:04:37.535 --> 00:04:39.695 to to create three-dimensional images
NOTE Confidence: 0.94852924

00:04:39.695 --> 00:04:40.995 of the tumor target.
NOTE Confidence: 0.9538291

00:04:41.375 --> 00:04:42.755 And that's coupled with,
NOTE Confidence: 0.9992017

00:04:43.440 --> 00:04:44.180 many technological
NOTE Confidence: 0.9859065

00:04:44.720 --> 00:04:46.580 advances in the linear accelerators
NOTE Confidence: 0.9859065

00:04:46.720 --> 00:04:47.380 that allow,
NOTE Confidence: 0.8635429

00:04:48.400 --> 00:04:50.260 the delivery of very complex,
NOTE Confidence: 0.97732925

00:04:51.440 --> 00:04:53.040 beam arrangements that really shape
NOTE Confidence: 0.97732925

00:04:53.040 --> 00:04:54.640 the dose distribution in a
NOTE Confidence: 0.97732925

00:04:54.640 --> 00:04:55.860 three-dimensional manner.
NOTE Confidence: 0.9817357

00:04:56.514 --> 00:04:58.115 And my sense is that
NOTE Confidence: 0.9817357

00:04:58.115 --> 00:05:00.435 by using those three-dimensional images
NOTE Confidence: 0.9817357

00:05:00.435 --> 00:05:02.275 like CT scans and with
NOTE Confidence: 0.9817357

00:05:02.275 --> 00:05:04.194 the changes in some of

NOTE Confidence: 0.9817357
00:05:04.194 --> 00:05:04.694 your,
NOTE Confidence: 0.9850942
00:05:05.315 --> 00:05:07.014 equipment that delivers radiation,
NOTE Confidence: 0.95083815
00:05:07.714 --> 00:05:08.914 the two things have happened.
NOTE Confidence: 0.95083815
00:05:08.914 --> 00:05:10.789 The treatment is far more
NOTE Confidence: 0.95083815
00:05:10.789 --> 00:05:11.289 effective,
NOTE Confidence: 0.9915035
00:05:11.990 --> 00:05:13.289 and at the same time,
NOTE Confidence: 0.9915035
00:05:13.349 --> 00:05:15.190 you can spare patients a
NOTE Confidence: 0.9915035
00:05:15.190 --> 00:05:16.389 lot of the side effects
NOTE Confidence: 0.9915035
00:05:16.389 --> 00:05:17.430 that used to be pretty
NOTE Confidence: 0.9915035
00:05:17.430 --> 00:05:17.930 commonplace.
NOTE Confidence: 0.9845463
00:05:18.710 --> 00:05:20.150 That's right. Because now we
NOTE Confidence: 0.9845463
00:05:20.150 --> 00:05:21.930 can, shape the dose distribution
NOTE Confidence: 0.98972744
00:05:22.310 --> 00:05:23.289 a lot more conformally
NOTE Confidence: 0.999733
00:05:23.589 --> 00:05:24.889 to the tumor itself
NOTE Confidence: 0.969301
00:05:25.515 --> 00:05:27.435 and substantially reduce the dose
NOTE Confidence: 0.969301

00:05:27.435 --> 00:05:28.735 to surrounding tissues.
NOTE Confidence: 0.9653506

00:05:29.275 --> 00:05:29.675 So,
NOTE Confidence: 0.93062246

00:05:30.075 --> 00:05:32.154 that's allowed us to deliver
NOTE Confidence: 0.93062246

00:05:32.154 --> 00:05:32.815 the treatments,
NOTE Confidence: 0.961471

00:05:33.435 --> 00:05:35.275 much more safely with less
NOTE Confidence: 0.961471

00:05:35.275 --> 00:05:36.015 side effect.
NOTE Confidence: 0.98517853

00:05:36.714 --> 00:05:38.235 And in some cases, we
NOTE Confidence: 0.98517853

00:05:38.235 --> 00:05:39.920 can give a higher dose
NOTE Confidence: 0.98517853

00:05:39.920 --> 00:05:41.600 each day and and reduce
NOTE Confidence: 0.98517853

00:05:41.600 --> 00:05:42.580 the number of,
NOTE Confidence: 0.9677575

00:05:43.280 --> 00:05:45.040 days of treatment that that's
NOTE Confidence: 0.9677575

00:05:45.040 --> 00:05:45.520 also,
NOTE Confidence: 0.98016626

00:05:45.840 --> 00:05:47.840 a benefit to patients. Now
NOTE Confidence: 0.98016626

00:05:47.840 --> 00:05:49.360 before we get into some
NOTE Confidence: 0.98016626

00:05:49.360 --> 00:05:50.500 additional advances,
NOTE Confidence: 0.9991252

00:05:50.985 --> 00:05:52.505 maybe you could just comment

NOTE Confidence: 0.9991252

00:05:52.505 --> 00:05:54.665 on some of the myths

NOTE Confidence: 0.9991252

00:05:54.665 --> 00:05:56.525 that people still carry around

NOTE Confidence: 0.88518363

00:05:57.225 --> 00:05:58.125 about radiation.

NOTE Confidence: 0.9724888

00:05:59.065 --> 00:06:00.044 You know, in

NOTE Confidence: 0.98421955

00:06:00.665 --> 00:06:01.865 not such a different way

NOTE Confidence: 0.98421955

00:06:01.865 --> 00:06:02.925 than with chemotherapy,

NOTE Confidence: 0.9968039

00:06:03.225 --> 00:06:03.865 there are a lot of

NOTE Confidence: 0.9968039

00:06:03.865 --> 00:06:05.310 patients who come see us

NOTE Confidence: 0.9991517

00:06:05.790 --> 00:06:08.210 and have preconceived notions about

NOTE Confidence: 0.96337736

00:06:08.830 --> 00:06:10.190 what these treatments are like

NOTE Confidence: 0.96337736

00:06:10.190 --> 00:06:11.310 and will come in saying,

NOTE Confidence: 0.96337736

00:06:11.310 --> 00:06:12.510 well, I'm never doing that

NOTE Confidence: 0.96337736

00:06:12.510 --> 00:06:13.490 because my,

NOTE Confidence: 0.9946234

00:06:13.950 --> 00:06:15.810 you know, great aunt received

NOTE Confidence: 0.9946234

00:06:15.870 --> 00:06:18.050 that and had some terrible

NOTE Confidence: 0.9946234

00:06:18.190 --> 00:06:18.690 problem.
NOTE Confidence: 0.99660337

00:06:19.964 --> 00:06:21.265 What are the specific
NOTE Confidence: 0.99950325

00:06:22.205 --> 00:06:22.705 misunderstandings
NOTE Confidence: 0.99632317

00:06:23.085 --> 00:06:23.904 about radiation?
NOTE Confidence: 0.98822945

00:06:24.925 --> 00:06:26.125 Well, I think that,
NOTE Confidence: 0.9745357

00:06:27.005 --> 00:06:27.725 one is,
NOTE Confidence: 0.95722365

00:06:28.285 --> 00:06:29.805 what we're alluding to before
NOTE Confidence: 0.95722365

00:06:29.805 --> 00:06:30.785 is, you know,
NOTE Confidence: 0.9394385

00:06:31.165 --> 00:06:33.325 historically, some people may remember
NOTE Confidence: 0.9394385

00:06:33.325 --> 00:06:33.825 that,
NOTE Confidence: 0.9797391

00:06:34.320 --> 00:06:35.680 people treated with sort of
NOTE Confidence: 0.9797391

00:06:35.680 --> 00:06:37.440 the older fashioned ways of
NOTE Confidence: 0.9797391

00:06:37.440 --> 00:06:38.980 giving radiation developed
NOTE Confidence: 0.9956814

00:06:39.440 --> 00:06:40.260 skin burns
NOTE Confidence: 0.8237263

00:06:41.199 --> 00:06:41.699 that
NOTE Confidence: 0.93189037

00:06:43.040 --> 00:06:45.199 were very challenging to treat

NOTE Confidence: 0.93189037
00:06:45.199 --> 00:06:46.580 and to heal. But
NOTE Confidence: 0.94406825
00:06:47.040 --> 00:06:48.320 the advances that we just
NOTE Confidence: 0.94406825
00:06:48.320 --> 00:06:49.620 talked about in
NOTE Confidence: 0.91923016
00:06:50.295 --> 00:06:52.714 delivery of radiation more deeply
NOTE Confidence: 0.91923016
00:06:52.855 --> 00:06:54.295 into the body and sparing
NOTE Confidence: 0.91923016
00:06:54.295 --> 00:06:55.995 the skin with shape beams,
NOTE Confidence: 0.9983781
00:06:57.335 --> 00:06:59.035 has allowed us to substantially
NOTE Confidence: 0.9983852
00:06:59.415 --> 00:06:59.915 avoid
NOTE Confidence: 0.8830166
00:07:00.855 --> 00:07:01.755 the skin damage
NOTE Confidence: 0.9420005
00:07:02.250 --> 00:07:02.990 and also,
NOTE Confidence: 0.9676184
00:07:03.370 --> 00:07:04.830 side effects to other,
NOTE Confidence: 0.9945199
00:07:05.450 --> 00:07:05.950 tissues.
NOTE Confidence: 0.894338
00:07:07.050 --> 00:07:07.550 So,
NOTE Confidence: 0.9236667
00:07:08.330 --> 00:07:10.030 not saying that doesn't sometimes
NOTE Confidence: 0.9236667
00:07:10.090 --> 00:07:11.450 happen. There is,
NOTE Confidence: 0.9901239

00:07:11.850 --> 00:07:12.830 can be some
NOTE Confidence: 0.94182724

00:07:13.210 --> 00:07:14.330 side effects to the skin,
NOTE Confidence: 0.94182724

00:07:14.330 --> 00:07:15.690 but it's it's much much
NOTE Confidence: 0.94182724

00:07:15.690 --> 00:07:17.050 less than it used to
NOTE Confidence: 0.94182724

00:07:17.050 --> 00:07:17.550 be.
NOTE Confidence: 0.9297714

00:07:18.235 --> 00:07:19.354 And the skin and for
NOTE Confidence: 0.9297714

00:07:19.354 --> 00:07:21.615 that matter, other organs too.
NOTE Confidence: 0.9297714

00:07:21.675 --> 00:07:23.194 Yeah. So so, you know,
NOTE Confidence: 0.9297714

00:07:23.194 --> 00:07:24.715 there is some,
NOTE Confidence: 0.97470784

00:07:25.115 --> 00:07:26.555 effect of radiation as it
NOTE Confidence: 0.97470784

00:07:26.555 --> 00:07:28.414 passes through healthy tissue, and
NOTE Confidence: 0.97470784

00:07:28.555 --> 00:07:29.995 sometimes that can lead to,
NOTE Confidence: 0.97470784

00:07:30.315 --> 00:07:32.074 some fatigue and temporary loss
NOTE Confidence: 0.97470784

00:07:32.074 --> 00:07:32.655 of energy.
NOTE Confidence: 0.95752877

00:07:33.530 --> 00:07:35.610 Sometimes if, patients are treated
NOTE Confidence: 0.95752877

00:07:35.610 --> 00:07:37.130 in the, area of the

NOTE Confidence: 0.95752877
00:07:37.130 --> 00:07:38.330 head and neck, they may
NOTE Confidence: 0.95752877
00:07:38.330 --> 00:07:39.710 develop dry mouth,
NOTE Confidence: 0.9873238
00:07:40.730 --> 00:07:41.850 or if they're treated in
NOTE Confidence: 0.9873238
00:07:41.850 --> 00:07:43.050 the GI tract, they may
NOTE Confidence: 0.9873238
00:07:43.050 --> 00:07:44.110 have some symptoms,
NOTE Confidence: 0.9692505
00:07:45.050 --> 00:07:47.050 associated with that. But, usually
NOTE Confidence: 0.9692505
00:07:47.050 --> 00:07:48.750 these symptoms fade over time.
NOTE Confidence: 0.9692505
00:07:49.005 --> 00:07:49.885 What are some of the
NOTE Confidence: 0.9692505
00:07:49.885 --> 00:07:51.585 most common uses of radiation?
NOTE Confidence: 0.98433125
00:07:52.045 --> 00:07:53.485 About sixty percent of all
NOTE Confidence: 0.98433125
00:07:53.485 --> 00:07:54.305 cancer patients,
NOTE Confidence: 0.9258269
00:07:54.685 --> 00:07:56.545 are treated with radiation and
NOTE Confidence: 0.9258269
00:07:56.605 --> 00:07:57.265 and and,
NOTE Confidence: 0.9985477
00:07:57.805 --> 00:07:59.325 many different types of tumors
NOTE Confidence: 0.9985477
00:07:59.325 --> 00:07:59.985 are treated.
NOTE Confidence: 0.99415714

00:08:01.005 --> 00:08:01.745 You know,
NOTE Confidence: 0.9987728

00:08:02.125 --> 00:08:02.625 one
NOTE Confidence: 0.9600044

00:08:03.520 --> 00:08:05.199 very common treatment is for
NOTE Confidence: 0.9600044

00:08:05.199 --> 00:08:06.240 cancers of the head and
NOTE Confidence: 0.9600044

00:08:06.240 --> 00:08:09.039 neck where radiation is considered
NOTE Confidence: 0.9600044

00:08:09.039 --> 00:08:11.280 a curative treatment often in
NOTE Confidence: 0.9600044

00:08:11.280 --> 00:08:12.580 combination with chemotherapy.
NOTE Confidence: 0.9988892

00:08:13.360 --> 00:08:14.240 We do a lot of
NOTE Confidence: 0.9988892

00:08:14.240 --> 00:08:16.159 radiation treatments for breast cancer,
NOTE Confidence: 0.9988892

00:08:16.159 --> 00:08:17.379 prostate cancer,
NOTE Confidence: 0.9940846

00:08:18.014 --> 00:08:18.755 brain tumors,
NOTE Confidence: 0.95504797

00:08:19.775 --> 00:08:21.535 and, tumors of the GI
NOTE Confidence: 0.95504797

00:08:21.535 --> 00:08:22.915 tract. I mentioned,
NOTE Confidence: 0.8422987

00:08:24.574 --> 00:08:25.074 gynecologic
NOTE Confidence: 0.9995365

00:08:25.375 --> 00:08:25.875 malignancies
NOTE Confidence: 0.88905346

00:08:26.414 --> 00:08:28.835 where radiation is very effective

NOTE Confidence: 0.88905346
00:08:28.895 --> 00:08:29.535 and and,
NOTE Confidence: 0.998095
00:08:30.095 --> 00:08:31.235 routinely achieves
NOTE Confidence: 0.9943047
00:08:32.000 --> 00:08:33.440 curative effect in many of
NOTE Confidence: 0.9943047
00:08:33.440 --> 00:08:34.179 those scenarios.
NOTE Confidence: 0.99261093
00:08:34.800 --> 00:08:36.400 And in some cases, these
NOTE Confidence: 0.99261093
00:08:36.400 --> 00:08:36.900 are
NOTE Confidence: 0.97567236
00:08:37.280 --> 00:08:39.440 this is a substitute for
NOTE Confidence: 0.97567236
00:08:39.440 --> 00:08:41.059 surgery, and in some cases,
NOTE Confidence: 0.97567236
00:08:41.120 --> 00:08:42.880 it's done in conjunction with
NOTE Confidence: 0.97567236
00:08:42.880 --> 00:08:44.320 surgery. Yeah. That's right. For
NOTE Confidence: 0.97567236
00:08:44.480 --> 00:08:45.300 you know, radiation
NOTE Confidence: 0.998683
00:08:46.005 --> 00:08:48.184 is particularly effective for localized
NOTE Confidence: 0.998683
00:08:48.325 --> 00:08:48.825 disease
NOTE Confidence: 0.9526823
00:08:49.365 --> 00:08:50.745 and can be an alternative
NOTE Confidence: 0.9526823
00:08:50.804 --> 00:08:52.425 to surgery in some cases,
NOTE Confidence: 0.9876934

00:08:52.965 --> 00:08:55.125 either because the individual is
NOTE Confidence: 0.9876934

00:08:55.125 --> 00:08:56.745 not medically able to undergo
NOTE Confidence: 0.37226805

00:08:57.525 --> 00:08:58.025 a
NOTE Confidence: 0.87850535

00:08:58.720 --> 00:08:59.220 operation,
NOTE Confidence: 0.9687984

00:09:00.320 --> 00:09:01.059 or because,
NOTE Confidence: 0.7290511

00:09:01.760 --> 00:09:02.080 the,
NOTE Confidence: 0.97721654

00:09:03.200 --> 00:09:04.720 the morbidity or side effects
NOTE Confidence: 0.97721654

00:09:04.720 --> 00:09:06.480 of getting radiation may actually
NOTE Confidence: 0.97721654

00:09:06.480 --> 00:09:06.980 be,
NOTE Confidence: 0.976867

00:09:07.679 --> 00:09:09.779 more favorable than a surgical
NOTE Confidence: 0.976867

00:09:09.840 --> 00:09:10.340 intervention.
NOTE Confidence: 0.9577737

00:09:10.720 --> 00:09:12.179 Not so many years ago
NOTE Confidence: 0.9577737

00:09:12.320 --> 00:09:14.445 when someone would have cancer
NOTE Confidence: 0.9577737

00:09:14.445 --> 00:09:16.285 that unfortunately would spread to
NOTE Confidence: 0.9577737

00:09:16.285 --> 00:09:17.184 their brain,
NOTE Confidence: 0.9250838

00:09:18.285 --> 00:09:19.965 they very commonly would re

NOTE Confidence: 0.9250838
00:09:20.125 --> 00:09:20.945 get radiation
NOTE Confidence: 0.96504647
00:09:21.885 --> 00:09:23.645 to the entire brain, to
NOTE Confidence: 0.96504647
00:09:23.645 --> 00:09:25.184 the whole head essentially.
NOTE Confidence: 0.9492086
00:09:26.399 --> 00:09:27.059 And increasingly
NOTE Confidence: 0.95638186
00:09:27.920 --> 00:09:29.600 over the years, it seems
NOTE Confidence: 0.95638186
00:09:29.600 --> 00:09:30.879 that that's not the case,
NOTE Confidence: 0.95638186
00:09:30.879 --> 00:09:32.339 and treatments that are
NOTE Confidence: 0.99783605
00:09:32.720 --> 00:09:34.019 referred to as either
NOTE Confidence: 0.7908092
00:09:34.399 --> 00:09:35.620 stair stereotactic
NOTE Confidence: 0.98678154
00:09:36.000 --> 00:09:36.500 radiosurgery
NOTE Confidence: 0.985683
00:09:36.879 --> 00:09:38.205 or gamma knife
NOTE Confidence: 0.99732584
00:09:38.765 --> 00:09:40.765 have been used and have
NOTE Confidence: 0.99732584
00:09:40.765 --> 00:09:41.825 been very effective.
NOTE Confidence: 0.99917096
00:09:42.205 --> 00:09:42.925 Can you tell us a
NOTE Confidence: 0.99917096
00:09:42.925 --> 00:09:44.865 little bit about those treatments?
NOTE Confidence: 0.9870305

00:09:45.405 --> 00:09:47.085 Yes. So so you're absolutely
NOTE Confidence: 0.9870305

00:09:47.085 --> 00:09:47.885 right that,
NOTE Confidence: 0.9991121

00:09:48.285 --> 00:09:49.665 you know, years ago,
NOTE Confidence: 0.96656483

00:09:50.125 --> 00:09:52.465 for, metastases in the brain,
NOTE Confidence: 0.96656483

00:09:52.690 --> 00:09:53.730 treatment would be given to
NOTE Confidence: 0.96656483

00:09:53.730 --> 00:09:54.610 what we call the whole
NOTE Confidence: 0.96656483

00:09:54.610 --> 00:09:56.130 brain, which is basically the
NOTE Confidence: 0.96656483

00:09:56.130 --> 00:09:56.630 upper
NOTE Confidence: 0.95752054

00:09:57.090 --> 00:09:58.610 part of the head through
NOTE Confidence: 0.95752054

00:09:58.610 --> 00:10:00.770 and through. But the advances
NOTE Confidence: 0.95752054

00:10:00.770 --> 00:10:02.130 that I was alluding to
NOTE Confidence: 0.95752054

00:10:02.130 --> 00:10:02.790 in terms
NOTE Confidence: 0.9142076

00:10:03.810 --> 00:10:05.250 of the technology, the treatment
NOTE Confidence: 0.9142076

00:10:05.250 --> 00:10:07.350 machines, and also specialized devices
NOTE Confidence: 0.9142076

00:10:07.410 --> 00:10:08.475 like the gamma knife,
NOTE Confidence: 0.97546625

00:10:09.115 --> 00:10:11.675 allows very focused treatment of

NOTE Confidence: 0.97546625
00:10:11.675 --> 00:10:13.535 individual metastatic lesions,
NOTE Confidence: 0.9834915
00:10:15.194 --> 00:10:17.434 with really exquisite precision that
NOTE Confidence: 0.9834915
00:10:17.434 --> 00:10:17.934 allow
NOTE Confidence: 0.91441107
00:10:18.394 --> 00:10:19.694 a good deal of sparing
NOTE Confidence: 0.98717517
00:10:19.995 --> 00:10:22.415 of the surrounding healthy brain.
NOTE Confidence: 0.99499047
00:10:22.850 --> 00:10:24.210 So now it's pretty much
NOTE Confidence: 0.99499047
00:10:24.210 --> 00:10:25.750 standard of care to
NOTE Confidence: 0.9459065
00:10:26.130 --> 00:10:26.530 treat,
NOTE Confidence: 0.949018
00:10:27.170 --> 00:10:29.590 the metastatic lesions fairly aggressively,
NOTE Confidence: 0.949018
00:10:29.650 --> 00:10:31.350 but with highly focused treatment.
NOTE Confidence: 0.96002936
00:10:32.050 --> 00:10:33.410 And the Gamma Knife actually
NOTE Confidence: 0.96002936
00:10:33.410 --> 00:10:34.210 is one of the best
NOTE Confidence: 0.96002936
00:10:34.210 --> 00:10:35.490 devices to do that for
NOTE Confidence: 0.96002936
00:10:35.490 --> 00:10:37.250 brain lesions because of its,
NOTE Confidence: 0.96002936
00:10:37.490 --> 00:10:38.150 high precision.
NOTE Confidence: 0.9973461

00:10:38.795 --> 00:10:40.415 I mean, this has really
NOTE Confidence: 0.99879444

00:10:41.195 --> 00:10:41.695 transformed
NOTE Confidence: 0.9757833

00:10:41.995 --> 00:10:43.455 in many ways the treatment
NOTE Confidence: 0.9757833

00:10:43.515 --> 00:10:44.875 of cancer that has spread
NOTE Confidence: 0.9757833

00:10:44.875 --> 00:10:45.695 to the brain
NOTE Confidence: 0.97081345

00:10:46.155 --> 00:10:48.495 and has allowed people to
NOTE Confidence: 0.93759453

00:10:48.875 --> 00:10:50.395 live longer and at the
NOTE Confidence: 0.93759453

00:10:50.395 --> 00:10:52.415 same time live much better.
NOTE Confidence: 0.96311754

00:10:52.949 --> 00:10:54.149 Yeah. That's right, and it's
NOTE Confidence: 0.96311754

00:10:54.149 --> 00:10:56.309 become especially important as systemic
NOTE Confidence: 0.96311754

00:10:56.309 --> 00:10:57.529 therapies have improved.
NOTE Confidence: 0.91747177

00:10:58.629 --> 00:10:59.990 So now we are, like
NOTE Confidence: 0.91747177

00:10:59.990 --> 00:11:00.970 I said, taking
NOTE Confidence: 0.80870885

00:11:01.670 --> 00:11:02.490 a more aggressive
NOTE Confidence: 0.9514476

00:11:02.870 --> 00:11:05.050 approach to, trying to,
NOTE Confidence: 0.9710512

00:11:06.069 --> 00:11:08.089 treat, lesions in the brain

NOTE Confidence: 0.9973655

00:11:08.415 --> 00:11:10.334 when, the systemic disease can

NOTE Confidence: 0.9973655

00:11:10.334 --> 00:11:11.955 be controlled by other approaches.

NOTE Confidence: 0.9815845

00:11:12.415 --> 00:11:13.535 It seems that there are

NOTE Confidence: 0.9815845

00:11:13.535 --> 00:11:16.575 even newer approaches, and you

NOTE Confidence: 0.9815845

00:11:16.575 --> 00:11:17.714 have a new machine

NOTE Confidence: 0.9997485

00:11:18.415 --> 00:11:19.154 that gives

NOTE Confidence: 0.94129336

00:11:19.535 --> 00:11:20.834 guided radiation.

NOTE Confidence: 0.9819255

00:11:21.375 --> 00:11:22.760 And maybe you can tell

NOTE Confidence: 0.9819255

00:11:22.760 --> 00:11:23.720 us a little bit about

NOTE Confidence: 0.9819255

00:11:23.720 --> 00:11:24.460 that, and

NOTE Confidence: 0.9908165

00:11:25.000 --> 00:11:25.580 and what's

NOTE Confidence: 0.9830408

00:11:25.960 --> 00:11:27.240 what kind of guidance is

NOTE Confidence: 0.9830408

00:11:27.240 --> 00:11:29.080 used? Yeah. So this is

NOTE Confidence: 0.9830408

00:11:29.080 --> 00:11:30.920 along the lines of, what

NOTE Confidence: 0.9830408

00:11:30.920 --> 00:11:32.600 we call image guided therapy,

NOTE Confidence: 0.9830408

00:11:32.600 --> 00:11:34.200 which in which the linear
NOTE Confidence: 0.9830408

00:11:34.200 --> 00:11:36.280 accelerators have an onboard imaging
NOTE Confidence: 0.9830408

00:11:36.280 --> 00:11:37.420 device to help,
NOTE Confidence: 0.8992373

00:11:38.735 --> 00:11:39.635 us evaluate
NOTE Confidence: 0.9111177

00:11:40.735 --> 00:11:42.035 and modify the treatment,
NOTE Confidence: 0.95318735

00:11:42.775 --> 00:11:44.095 you know, at the time
NOTE Confidence: 0.95318735

00:11:44.095 --> 00:11:44.755 the patient
NOTE Confidence: 0.8905596

00:11:46.175 --> 00:11:47.695 is in the machine and
NOTE Confidence: 0.8905596

00:11:47.695 --> 00:11:49.295 in some cases almost in
NOTE Confidence: 0.8905596

00:11:49.295 --> 00:11:50.115 real time.
NOTE Confidence: 0.95348525

00:11:51.160 --> 00:11:53.400 This approach started with, CT
NOTE Confidence: 0.95348525

00:11:53.400 --> 00:11:55.260 scan and MR scan,
NOTE Confidence: 0.9444651

00:11:56.280 --> 00:11:58.040 included in Lenox, but this
NOTE Confidence: 0.9444651

00:11:58.040 --> 00:12:00.620 new biologically guided therapy incorporates
NOTE Confidence: 0.9444651

00:12:00.760 --> 00:12:02.360 a PET scanner or PET
NOTE Confidence: 0.9444651

00:12:02.360 --> 00:12:04.155 imager in the device. So

NOTE Confidence: 0.9444651

00:12:04.315 --> 00:12:05.855 a PET scanner images,

NOTE Confidence: 0.99297106

00:12:06.875 --> 00:12:09.375 positron emissions from radioactive tracers

NOTE Confidence: 0.8908592

00:12:10.235 --> 00:12:10.555 that,

NOTE Confidence: 0.97445685

00:12:11.115 --> 00:12:12.975 accumulate in the tumor when

NOTE Confidence: 0.97445685

00:12:13.035 --> 00:12:13.515 certain,

NOTE Confidence: 0.9813031

00:12:13.915 --> 00:12:15.115 compounds are given to the

NOTE Confidence: 0.9813031

00:12:15.115 --> 00:12:16.800 patient ahead of time. And

NOTE Confidence: 0.9813031

00:12:16.800 --> 00:12:18.880 that allows us to account

NOTE Confidence: 0.9813031

00:12:18.880 --> 00:12:20.880 for the localization of the

NOTE Confidence: 0.9813031

00:12:20.880 --> 00:12:21.380 tumor,

NOTE Confidence: 0.96417683

00:12:22.480 --> 00:12:24.240 and also its motion within

NOTE Confidence: 0.96417683

00:12:24.240 --> 00:12:25.600 the patient, and in some

NOTE Confidence: 0.96417683

00:12:25.600 --> 00:12:27.520 cases depending on the tracer

NOTE Confidence: 0.96417683

00:12:27.520 --> 00:12:28.740 we use on its biological

NOTE Confidence: 0.96417683

00:12:28.960 --> 00:12:29.460 properties.

NOTE Confidence: 0.985

00:12:30.080 --> 00:12:31.460 And then we can modify
NOTE Confidence: 0.89966303

00:12:32.615 --> 00:12:34.074 the treatment, beamlets,
NOTE Confidence: 0.9453735

00:12:34.934 --> 00:12:36.375 in real time based on
NOTE Confidence: 0.9453735

00:12:36.375 --> 00:12:38.154 the, positron emission,
NOTE Confidence: 0.9723301

00:12:39.014 --> 00:12:40.855 pattern. How much experience have
NOTE Confidence: 0.9723301

00:12:40.855 --> 00:12:41.815 you had with this so
NOTE Confidence: 0.9723301

00:12:41.815 --> 00:12:43.735 far? We've had it, going
NOTE Confidence: 0.9723301

00:12:43.735 --> 00:12:45.334 for about a year, and,
NOTE Confidence: 0.9839964

00:12:46.380 --> 00:12:47.740 actually, I think we have
NOTE Confidence: 0.9839964

00:12:47.740 --> 00:12:49.200 one of the largest experiences
NOTE Confidence: 0.9839964

00:12:49.340 --> 00:12:50.300 in the country with this.
NOTE Confidence: 0.9839964

00:12:50.300 --> 00:12:52.240 So we're getting more familiar
NOTE Confidence: 0.9839964

00:12:52.300 --> 00:12:53.420 with how to best,
NOTE Confidence: 0.9870507

00:12:54.220 --> 00:12:56.160 incorporate this technology into,
NOTE Confidence: 0.9992642

00:12:56.780 --> 00:12:58.000 our treatment of patients.
NOTE Confidence: 0.9853009

00:12:58.540 --> 00:13:00.720 So it's it's really taking

NOTE Confidence: 0.99872905
00:13:01.245 --> 00:13:02.865 taking the treatment even
NOTE Confidence: 0.999399
00:13:03.325 --> 00:13:04.765 a step further than you
NOTE Confidence: 0.999399
00:13:04.765 --> 00:13:06.365 would with just a CT
NOTE Confidence: 0.999399
00:13:06.365 --> 00:13:07.265 scan alone
NOTE Confidence: 0.71420646
00:13:07.725 --> 00:13:08.545 because with
NOTE Confidence: 0.9861991
00:13:09.005 --> 00:13:10.045 the PET part of that
NOTE Confidence: 0.9861991
00:13:10.045 --> 00:13:11.565 imaging, you can tell much
NOTE Confidence: 0.9861991
00:13:11.565 --> 00:13:12.925 more about what's going on
NOTE Confidence: 0.9861991
00:13:12.925 --> 00:13:14.285 in the tumor. Yeah. It
NOTE Confidence: 0.9861991
00:13:14.285 --> 00:13:15.405 has a new dimension. I
NOTE Confidence: 0.9861991
00:13:15.405 --> 00:13:17.149 mean, right now, it's primarily
NOTE Confidence: 0.9861991
00:13:17.370 --> 00:13:19.370 valuable for for accounting for
NOTE Confidence: 0.9861991
00:13:19.370 --> 00:13:21.449 motion, especially lesions in the
NOTE Confidence: 0.9861991
00:13:21.449 --> 00:13:22.910 lung where you have breathing,
NOTE Confidence: 0.9509913
00:13:23.850 --> 00:13:25.129 the the breathing cycle that
NOTE Confidence: 0.9509913

00:13:25.129 --> 00:13:26.029 causes motion.
NOTE Confidence: 0.99434924

00:13:26.970 --> 00:13:28.649 But we think that, down
NOTE Confidence: 0.99434924

00:13:28.649 --> 00:13:29.610 the road, we will have
NOTE Confidence: 0.99434924

00:13:29.610 --> 00:13:31.129 many other applications of the
NOTE Confidence: 0.99434924

00:13:31.129 --> 00:13:31.629 technology.
NOTE Confidence: 0.99155134

00:13:32.865 --> 00:13:34.065 Well, this is great. We're
NOTE Confidence: 0.99155134

00:13:34.065 --> 00:13:35.265 gonna take a break for
NOTE Confidence: 0.99155134

00:13:35.265 --> 00:13:36.545 just a minute. And when
NOTE Confidence: 0.99155134

00:13:36.545 --> 00:13:37.745 we come back, we're gonna
NOTE Confidence: 0.99155134

00:13:37.745 --> 00:13:39.525 talk a little more about
NOTE Confidence: 0.99155134

00:13:39.585 --> 00:13:41.265 how radiation works, and then
NOTE Confidence: 0.99155134

00:13:41.265 --> 00:13:42.705 we're gonna get into some
NOTE Confidence: 0.99155134

00:13:42.705 --> 00:13:44.245 of the research you've done
NOTE Confidence: 0.99155134

00:13:44.304 --> 00:13:45.365 related to that.
NOTE Confidence: 0.98519945

00:13:45.970 --> 00:13:47.650 Support for Yale Cancer Answers
NOTE Confidence: 0.98519945

00:13:47.650 --> 00:13:49.590 comes from Smilow Cancer Hospital,

NOTE Confidence: 0.98519945

00:13:49.890 --> 00:13:51.650 where all patients have access

NOTE Confidence: 0.98519945

00:13:51.650 --> 00:13:53.250 to cutting edge clinical trials

NOTE Confidence: 0.98519945

00:13:53.250 --> 00:13:55.330 at several convenient locations throughout

NOTE Confidence: 0.98519945

00:13:55.330 --> 00:13:55.990 the region.

NOTE Confidence: 0.9647773

00:13:56.370 --> 00:13:57.990 To learn more, visit [smilowcancer](http://smilowcancer.org)

NOTE Confidence: 0.9825418

00:13:58.370 --> 00:13:59.750 [hospital dot org](http://hospital.org).

NOTE Confidence: 0.98799294

00:14:01.904 --> 00:14:04.225 The American Cancer Society estimates

NOTE Confidence: 0.98799294

00:14:04.225 --> 00:14:05.345 that nearly one hundred and

NOTE Confidence: 0.98799294

00:14:05.345 --> 00:14:06.704 fifty thousand people in the

NOTE Confidence: 0.98799294

00:14:06.704 --> 00:14:08.005 U. S. Will be diagnosed

NOTE Confidence: 0.98799294

00:14:08.065 --> 00:14:10.065 with colorectal cancer this year

NOTE Confidence: 0.98799294

00:14:10.065 --> 00:14:10.565 alone.

NOTE Confidence: 0.9882225

00:14:11.024 --> 00:14:13.265 When detected early, colorectal cancer

NOTE Confidence: 0.9882225

00:14:13.265 --> 00:14:14.945 is easily treated and highly

NOTE Confidence: 0.9882225

00:14:14.945 --> 00:14:15.445 curable,

NOTE Confidence: 0.9989449

00:14:15.860 --> 00:14:16.900 and men and women over
NOTE Confidence: 0.9989449

00:14:16.900 --> 00:14:18.020 the age of forty five
NOTE Confidence: 0.9989449

00:14:18.020 --> 00:14:19.400 should have regular colonoscopies
NOTE Confidence: 0.99939996

00:14:19.860 --> 00:14:21.080 to screen for the disease.
NOTE Confidence: 0.9896938

00:14:21.700 --> 00:14:23.620 Patients with colorectal cancer have
NOTE Confidence: 0.9896938

00:14:23.620 --> 00:14:25.080 more hope than ever before,
NOTE Confidence: 0.9896938

00:14:25.300 --> 00:14:26.980 thanks to increased access to
NOTE Confidence: 0.9896938

00:14:26.980 --> 00:14:29.640 advanced therapies and specialized care.
NOTE Confidence: 0.95140123

00:14:30.075 --> 00:14:31.835 Clinical trials are currently underway
NOTE Confidence: 0.95140123

00:14:31.835 --> 00:14:34.475 at federally designated comprehensive cancer
NOTE Confidence: 0.95140123

00:14:34.475 --> 00:14:36.315 centers, such as Yale Cancer
NOTE Confidence: 0.95140123

00:14:36.315 --> 00:14:37.995 Center and its Milo Cancer
NOTE Confidence: 0.95140123

00:14:37.995 --> 00:14:38.495 Hospital,
NOTE Confidence: 0.9975308

00:14:38.795 --> 00:14:40.475 to test innovative new treatments
NOTE Confidence: 0.9975308

00:14:40.475 --> 00:14:41.855 for colorectal cancer.
NOTE Confidence: 0.9973013

00:14:42.380 --> 00:14:44.459 Tumor gene analysis has helped

NOTE Confidence: 0.9973013

00:14:44.459 --> 00:14:46.720 improve management of colorectal cancer

NOTE Confidence: 0.9973013

00:14:46.940 --> 00:14:48.940 by identifying the patients most

NOTE Confidence: 0.9973013

00:14:48.940 --> 00:14:50.800 likely to benefit from chemotherapy

NOTE Confidence: 0.97905904

00:14:51.420 --> 00:14:53.899 and newer targeted agents resulting

NOTE Confidence: 0.97905904

00:14:53.899 --> 00:14:55.680 in more patient specific treatment.

NOTE Confidence: 0.989866

00:14:56.445 --> 00:14:57.965 More information is available at

NOTE Confidence: 0.989866

00:14:57.965 --> 00:14:59.825 yale cancer center dot org.

NOTE Confidence: 0.989866

00:14:59.965 --> 00:15:01.725 You're listening to Connecticut Public

NOTE Confidence: 0.989866

00:15:01.725 --> 00:15:02.225 Radio.

NOTE Confidence: 0.9676658

00:15:03.005 --> 00:15:04.445 Good evening again. This is

NOTE Confidence: 0.9676658

00:15:04.445 --> 00:15:06.365 Eric Wyner with Yale Cancer

NOTE Confidence: 0.9676658

00:15:06.365 --> 00:15:08.705 Answers, and I'm here tonight

NOTE Confidence: 0.9676658

00:15:08.845 --> 00:15:10.305 with my guest,

NOTE Confidence: 0.9378652

00:15:10.800 --> 00:15:12.100 doctor Peter Glaser,

NOTE Confidence: 0.99806845

00:15:12.560 --> 00:15:14.100 who is a professor

NOTE Confidence: 0.9539453

00:15:14.400 --> 00:15:14.900 of,
NOTE Confidence: 0.9869278

00:15:15.760 --> 00:15:17.840 therapeutic radiology and a professor
NOTE Confidence: 0.9869278

00:15:17.840 --> 00:15:19.200 of genetics here at Yale
NOTE Confidence: 0.9869278

00:15:19.200 --> 00:15:20.740 School of Medicine and chair,
NOTE Confidence: 0.9994871

00:15:21.600 --> 00:15:23.060 of therapeutic radiology.
NOTE Confidence: 0.9994349

00:15:23.680 --> 00:15:24.960 Can you tell us a
NOTE Confidence: 0.9994349

00:15:24.960 --> 00:15:25.779 little bit
NOTE Confidence: 0.9997471

00:15:26.355 --> 00:15:26.855 about
NOTE Confidence: 0.9997988

00:15:27.155 --> 00:15:28.935 how it is that radiation
NOTE Confidence: 0.9926603

00:15:29.475 --> 00:15:31.335 on a on a cellular
NOTE Confidence: 0.9926603

00:15:31.475 --> 00:15:31.975 level
NOTE Confidence: 0.9949279

00:15:32.275 --> 00:15:34.035 kills cancer cells? What does
NOTE Confidence: 0.9949279

00:15:34.035 --> 00:15:35.555 it do that that makes
NOTE Confidence: 0.9949279

00:15:35.555 --> 00:15:36.455 them die?
NOTE Confidence: 0.9893445

00:15:37.315 --> 00:15:37.715 So,
NOTE Confidence: 0.999589

00:15:38.195 --> 00:15:38.695 radiation

NOTE Confidence: 0.96470606

00:15:39.075 --> 00:15:40.215 that that we use,

NOTE Confidence: 0.84999245

00:15:40.959 --> 00:15:42.399 clinically to treat cancer is

NOTE Confidence: 0.84999245

00:15:42.399 --> 00:15:42.899 sometimes

NOTE Confidence: 0.9944219

00:15:43.279 --> 00:15:43.779 classified

NOTE Confidence: 0.9985743

00:15:44.080 --> 00:15:45.540 as ionizing radiation

NOTE Confidence: 0.9275751

00:15:46.080 --> 00:15:48.320 to differentiate it from other

NOTE Confidence: 0.9275751

00:15:48.320 --> 00:15:49.220 forms of,

NOTE Confidence: 0.87444776

00:15:50.959 --> 00:15:52.880 radiation including photons, which is

NOTE Confidence: 0.87444776

00:15:52.880 --> 00:15:53.860 visible light.

NOTE Confidence: 0.85954887

00:15:54.320 --> 00:15:55.140 And and

NOTE Confidence: 0.95287067

00:15:55.764 --> 00:15:56.964 and what that means is

NOTE Confidence: 0.95287067

00:15:56.964 --> 00:15:59.305 that the radiation, x-ray radiation

NOTE Confidence: 0.95287067

00:15:59.365 --> 00:16:01.385 goes into cancer cells

NOTE Confidence: 0.98957825

00:16:02.005 --> 00:16:03.845 and causes ionization of the

NOTE Confidence: 0.98957825

00:16:03.845 --> 00:16:04.345 molecules

NOTE Confidence: 0.98295987

00:16:04.885 --> 00:16:06.644 inside the cell, and that
NOTE Confidence: 0.98295987

00:16:06.644 --> 00:16:07.685 leads to a lot of
NOTE Confidence: 0.98295987

00:16:07.685 --> 00:16:09.445 chemical reactions that damage the
NOTE Confidence: 0.98295987

00:16:09.445 --> 00:16:09.945 DNA.
NOTE Confidence: 0.8771124

00:16:10.770 --> 00:16:11.510 So fundamentally,
NOTE Confidence: 0.996021

00:16:11.810 --> 00:16:13.810 radiation causes DNA damage in
NOTE Confidence: 0.996021

00:16:13.810 --> 00:16:14.710 cancer cells
NOTE Confidence: 0.9020197

00:16:15.170 --> 00:16:16.550 and if we can provide
NOTE Confidence: 0.9020197

00:16:16.610 --> 00:16:18.950 sufficient damage, the cells cannot,
NOTE Confidence: 0.9882677

00:16:20.130 --> 00:16:22.050 fix themselves well enough to
NOTE Confidence: 0.9882677

00:16:22.050 --> 00:16:22.550 recover
NOTE Confidence: 0.94986635

00:16:22.975 --> 00:16:24.495 and that leads to a
NOTE Confidence: 0.94986635

00:16:24.495 --> 00:16:26.095 destruction of the tumor and,
NOTE Confidence: 0.94986635

00:16:26.335 --> 00:16:27.235 tumor regression.
NOTE Confidence: 0.9883442

00:16:27.935 --> 00:16:29.795 And the DNA is essentially
NOTE Confidence: 0.93754345

00:16:30.415 --> 00:16:31.615 the brain of the cancer

NOTE Confidence: 0.93754345

00:16:31.615 --> 00:16:33.455 cell? Yeah. Well, DNA, like

NOTE Confidence: 0.93754345

00:16:33.455 --> 00:16:35.135 in all cells, is, has

NOTE Confidence: 0.93754345

00:16:35.135 --> 00:16:36.815 the blueprint for how a

NOTE Confidence: 0.93754345

00:16:36.815 --> 00:16:37.555 cell functions,

NOTE Confidence: 0.99932164

00:16:38.310 --> 00:16:39.930 and, you know, DNA

NOTE Confidence: 0.9841659

00:16:40.390 --> 00:16:41.750 leads to the production of

NOTE Confidence: 0.9841659

00:16:41.750 --> 00:16:43.670 downstream molecules like RNA and

NOTE Confidence: 0.9841659

00:16:43.670 --> 00:16:45.270 proteins. So if you get

NOTE Confidence: 0.9841659

00:16:45.270 --> 00:16:46.890 the DNA, then you basically

NOTE Confidence: 0.9841659

00:16:46.950 --> 00:16:48.730 block all of cellular functions

NOTE Confidence: 0.9977467

00:16:49.110 --> 00:16:50.070 and the ability of the

NOTE Confidence: 0.9977467

00:16:50.070 --> 00:16:50.970 cell to survive.

NOTE Confidence: 0.9934935

00:16:51.430 --> 00:16:52.870 Now one of the things

NOTE Confidence: 0.9934935

00:16:52.870 --> 00:16:53.370 that

NOTE Confidence: 0.99040234

00:16:54.105 --> 00:16:55.625 one hears as a doctor

NOTE Confidence: 0.99040234

00:16:55.625 --> 00:16:57.404 from patients is the question,
NOTE Confidence: 0.9980239

00:16:57.705 --> 00:16:59.005 well, doesn't radiation
NOTE Confidence: 0.9844425

00:16:59.464 --> 00:17:00.445 cause cancer?
NOTE Confidence: 0.9919805

00:17:01.065 --> 00:17:02.665 And I think people are
NOTE Confidence: 0.9919805

00:17:02.665 --> 00:17:03.964 often thinking about,
NOTE Confidence: 0.9630483

00:17:04.984 --> 00:17:06.825 the fact that, you know,
NOTE Confidence: 0.9630483

00:17:06.825 --> 00:17:07.325 repeated,
NOTE Confidence: 0.984136

00:17:08.800 --> 00:17:11.040 imaging studies are associated with
NOTE Confidence: 0.984136

00:17:11.040 --> 00:17:12.560 a very small increased risk
NOTE Confidence: 0.984136

00:17:12.560 --> 00:17:14.420 in cancer in certain circumstances.
NOTE Confidence: 0.977119

00:17:15.680 --> 00:17:17.119 Is that a question that
NOTE Confidence: 0.977119

00:17:17.119 --> 00:17:18.560 that all of you get
NOTE Confidence: 0.977119

00:17:18.560 --> 00:17:20.160 asked a fair amount? Yeah.
NOTE Confidence: 0.977119

00:17:20.160 --> 00:17:21.680 Yes. We sometimes talk about
NOTE Confidence: 0.977119

00:17:21.680 --> 00:17:23.415 that with with patients. I
NOTE Confidence: 0.977119

00:17:23.415 --> 00:17:24.615 I think that it, you

NOTE Confidence: 0.977119
00:17:24.615 --> 00:17:26.475 know, it is known that,
NOTE Confidence: 0.99857396
00:17:26.855 --> 00:17:28.135 there is a link between
NOTE Confidence: 0.99857396
00:17:28.135 --> 00:17:29.994 radiation exposure and
NOTE Confidence: 0.7502995
00:17:30.535 --> 00:17:31.755 developing malignancies.
NOTE Confidence: 0.9918907
00:17:32.455 --> 00:17:33.415 I think this is one
NOTE Confidence: 0.9918907
00:17:33.415 --> 00:17:34.075 of the
NOTE Confidence: 0.9806618
00:17:34.535 --> 00:17:35.975 key reasons that we've worked
NOTE Confidence: 0.9806618
00:17:35.975 --> 00:17:37.515 so hard to develop technologies
NOTE Confidence: 0.9806618
00:17:37.734 --> 00:17:39.180 that focus the radiation
NOTE Confidence: 0.977048
00:17:40.040 --> 00:17:41.660 intensively on the tumor,
NOTE Confidence: 0.7435691
00:17:42.280 --> 00:17:42.600 and,
NOTE Confidence: 0.9967444
00:17:43.160 --> 00:17:44.440 work to spare the healthy
NOTE Confidence: 0.9967444
00:17:44.440 --> 00:17:44.940 tissue
NOTE Confidence: 0.99018466
00:17:45.320 --> 00:17:46.540 as much as we can.
NOTE Confidence: 0.9584448
00:17:47.720 --> 00:17:49.160 And, you know, we've studied
NOTE Confidence: 0.9584448

00:17:49.160 --> 00:17:50.200 this a lot in the
NOTE Confidence: 0.9584448

00:17:50.200 --> 00:17:52.460 field, and, the risk of
NOTE Confidence: 0.99758375

00:17:53.534 --> 00:17:54.514 secondary malignancies
NOTE Confidence: 0.9791086

00:17:54.894 --> 00:17:56.095 is not zero, but it's
NOTE Confidence: 0.9791086

00:17:56.095 --> 00:17:57.774 very low, especially for most
NOTE Confidence: 0.9791086

00:17:57.774 --> 00:17:58.595 adult patients.
NOTE Confidence: 0.97777367

00:17:59.215 --> 00:18:00.335 We worry a little bit
NOTE Confidence: 0.97777367

00:18:00.335 --> 00:18:01.934 more about children, which is
NOTE Confidence: 0.97777367

00:18:01.934 --> 00:18:03.294 one of the reasons that
NOTE Confidence: 0.97777367

00:18:03.294 --> 00:18:04.815 we we spend a lot
NOTE Confidence: 0.97777367

00:18:04.815 --> 00:18:06.894 of time in developing treatment
NOTE Confidence: 0.97777367

00:18:06.894 --> 00:18:08.550 approaches for children that are
NOTE Confidence: 0.97777367

00:18:08.869 --> 00:18:10.490 very highly focused. And
NOTE Confidence: 0.99366283

00:18:10.950 --> 00:18:12.250 one of the more recent,
NOTE Confidence: 0.96687096

00:18:12.790 --> 00:18:14.390 two elements along those lines
NOTE Confidence: 0.96687096

00:18:14.390 --> 00:18:15.590 is the use of proton

NOTE Confidence: 0.96687096
00:18:15.590 --> 00:18:16.330 beam therapy,
NOTE Confidence: 0.996529
00:18:16.869 --> 00:18:17.350 which is,
NOTE Confidence: 0.99446136
00:18:17.910 --> 00:18:18.490 you know,
NOTE Confidence: 0.93894964
00:18:19.430 --> 00:18:21.190 especially valuable for for treating
NOTE Confidence: 0.93894964
00:18:21.190 --> 00:18:21.690 children.
NOTE Confidence: 0.9790747
00:18:22.445 --> 00:18:22.945 And,
NOTE Confidence: 0.9902553
00:18:23.325 --> 00:18:24.765 there's gonna be a proton
NOTE Confidence: 0.9902553
00:18:24.765 --> 00:18:25.665 beam facility
NOTE Confidence: 0.99981683
00:18:26.125 --> 00:18:26.865 in Connecticut
NOTE Confidence: 0.97131664
00:18:27.244 --> 00:18:29.005 in the not distant future
NOTE Confidence: 0.97131664
00:18:29.005 --> 00:18:30.625 that we've been involved with.
NOTE Confidence: 0.97131664
00:18:30.685 --> 00:18:32.305 Yeah. That's right. So protons,
NOTE Confidence: 0.9501652
00:18:33.645 --> 00:18:35.025 are a type of ionizing
NOTE Confidence: 0.9501652
00:18:35.165 --> 00:18:36.925 radiation, but instead of x
NOTE Confidence: 0.9501652
00:18:36.925 --> 00:18:37.770 rays, they use
NOTE Confidence: 0.94872874

00:18:38.170 --> 00:18:40.109 protons, which are a subatomic
NOTE Confidence: 0.94872874

00:18:40.250 --> 00:18:40.750 particle,
NOTE Confidence: 0.86726725

00:18:41.530 --> 00:18:43.470 which they accel a machine
NOTE Confidence: 0.86726725

00:18:43.530 --> 00:18:45.230 called a cyclotron will accelerate.
NOTE Confidence: 0.971175

00:18:45.930 --> 00:18:46.910 And the protons,
NOTE Confidence: 0.9835828

00:18:47.450 --> 00:18:48.970 also enter into the tissue,
NOTE Confidence: 0.9835828

00:18:48.970 --> 00:18:50.190 but they have a special
NOTE Confidence: 0.95466405

00:18:50.755 --> 00:18:51.734 property because,
NOTE Confidence: 0.95821244

00:18:52.195 --> 00:18:53.635 they're a particle with mass
NOTE Confidence: 0.95821244

00:18:53.635 --> 00:18:55.475 that they enter tissue and
NOTE Confidence: 0.95821244

00:18:55.475 --> 00:18:57.234 they stop suddenly to deposit
NOTE Confidence: 0.95821244

00:18:57.234 --> 00:18:58.054 their dose.
NOTE Confidence: 0.9850017

00:18:58.515 --> 00:19:00.215 And that lets us tailor
NOTE Confidence: 0.79861

00:19:00.595 --> 00:19:01.095 the,
NOTE Confidence: 0.98362845

00:19:02.770 --> 00:19:04.869 delivery of the ionizing radiation,
NOTE Confidence: 0.87104505

00:19:05.490 --> 00:19:06.309 even better.

NOTE Confidence: 0.963572
00:19:06.850 --> 00:19:07.330 And,
NOTE Confidence: 0.97564983
00:19:07.970 --> 00:19:09.090 we think that it has
NOTE Confidence: 0.97564983
00:19:09.090 --> 00:19:10.390 some advantages. So,
NOTE Confidence: 0.98021406
00:19:10.930 --> 00:19:13.270 but developing proton beam facilities
NOTE Confidence: 0.98021406
00:19:13.330 --> 00:19:14.609 is not a simple endeavor.
NOTE Confidence: 0.98021406
00:19:14.609 --> 00:19:16.369 It's much more expensive and
NOTE Confidence: 0.98021406
00:19:16.369 --> 00:19:17.430 involved than,
NOTE Confidence: 0.92289317
00:19:18.305 --> 00:19:19.925 installing a regular LINAC.
NOTE Confidence: 0.970011
00:19:20.465 --> 00:19:22.065 And so there are not
NOTE Confidence: 0.970011
00:19:22.065 --> 00:19:23.125 many in the country,
NOTE Confidence: 0.95277196
00:19:23.905 --> 00:19:24.945 and there has there is
NOTE Confidence: 0.95277196
00:19:24.945 --> 00:19:26.385 not one in Connecticut right
NOTE Confidence: 0.95277196
00:19:26.385 --> 00:19:27.744 now, but Yale New Haven
NOTE Confidence: 0.95277196
00:19:27.744 --> 00:19:29.365 Health System and Hartford HealthCare
NOTE Confidence: 0.94577837
00:19:30.080 --> 00:19:30.900 have partnered,
NOTE Confidence: 0.910775

00:19:31.600 --> 00:19:33.359 and we recently did the
NOTE Confidence: 0.910775

00:19:33.359 --> 00:19:33.859 groundbreaking
NOTE Confidence: 0.83913493

00:19:34.160 --> 00:19:34.660 to,
NOTE Confidence: 0.96341705

00:19:35.600 --> 00:19:37.200 advance a new proton beam
NOTE Confidence: 0.96341705

00:19:37.200 --> 00:19:37.700 facility,
NOTE Confidence: 0.92682976

00:19:38.720 --> 00:19:39.840 in the center of the
NOTE Confidence: 0.92682976

00:19:39.840 --> 00:19:40.980 state that'll be,
NOTE Confidence: 0.9991468

00:19:41.520 --> 00:19:42.720 a resource for all of
NOTE Confidence: 0.9991468

00:19:42.720 --> 00:19:43.940 the people in the region.
NOTE Confidence: 0.9986903

00:19:44.395 --> 00:19:45.915 And the price tag for
NOTE Confidence: 0.9986903

00:19:45.915 --> 00:19:47.595 these kinds of facilities is
NOTE Confidence: 0.9986903

00:19:47.595 --> 00:19:48.255 in the
NOTE Confidence: 0.98676294

00:19:48.795 --> 00:19:50.575 tens of millions of dollars.
NOTE Confidence: 0.98676294

00:19:50.795 --> 00:19:51.755 Yeah. That's right.
NOTE Confidence: 0.99469215

00:19:52.155 --> 00:19:53.195 You know, this one is
NOTE Confidence: 0.99469215

00:19:53.195 --> 00:19:54.315 somewhere in the range of

NOTE Confidence: 0.99469215
00:19:54.315 --> 00:19:56.155 seventy million all in with
NOTE Confidence: 0.99469215
00:19:56.155 --> 00:19:57.600 all the construction and
NOTE Confidence: 0.79528487
00:19:58.160 --> 00:19:58.660 equipment.
NOTE Confidence: 0.9970613
00:19:59.520 --> 00:20:00.500 So that's correct.
NOTE Confidence: 0.9995575
00:20:00.880 --> 00:20:01.700 Can you
NOTE Confidence: 0.99380654
00:20:02.000 --> 00:20:03.840 talk about some of your
NOTE Confidence: 0.99380654
00:20:03.840 --> 00:20:04.340 research?
NOTE Confidence: 0.99855703
00:20:05.119 --> 00:20:05.619 And
NOTE Confidence: 0.9985343
00:20:06.240 --> 00:20:07.359 I know some of the
NOTE Confidence: 0.9985343
00:20:07.359 --> 00:20:08.980 recent research has
NOTE Confidence: 0.99948615
00:20:09.440 --> 00:20:10.660 related to the treatment
NOTE Confidence: 0.9465742
00:20:11.039 --> 00:20:11.539 of,
NOTE Confidence: 0.9997097
00:20:12.559 --> 00:20:13.380 what is
NOTE Confidence: 0.9992161
00:20:14.855 --> 00:20:16.315 often thought of as
NOTE Confidence: 0.95844424
00:20:16.934 --> 00:20:18.534 inherited breast cancer and other
NOTE Confidence: 0.95844424

00:20:18.534 --> 00:20:20.054 cancers that is cancers that
NOTE Confidence: 0.95844424

00:20:20.054 --> 00:20:21.975 arise in the setting of
NOTE Confidence: 0.95844424

00:20:21.975 --> 00:20:22.875 of BRCA
NOTE Confidence: 0.94804823

00:20:23.494 --> 00:20:23.994 mutations.
NOTE Confidence: 0.9986493

00:20:25.494 --> 00:20:27.174 But I know that your
NOTE Confidence: 0.9986493

00:20:27.174 --> 00:20:28.955 research career stretches
NOTE Confidence: 0.9702132

00:20:29.290 --> 00:20:30.830 pretty far back. And
NOTE Confidence: 0.9843176

00:20:31.210 --> 00:20:32.010 what are some of the
NOTE Confidence: 0.9843176

00:20:32.010 --> 00:20:33.130 things you've worked on over
NOTE Confidence: 0.9843176

00:20:33.130 --> 00:20:34.490 the years? And then maybe
NOTE Confidence: 0.9843176

00:20:34.490 --> 00:20:36.170 we can talk more about
NOTE Confidence: 0.9843176

00:20:36.170 --> 00:20:36.670 BRCA.
NOTE Confidence: 0.9108113

00:20:37.450 --> 00:20:38.650 Well, so yes. So I've
NOTE Confidence: 0.9108113

00:20:38.650 --> 00:20:40.030 been interested in how,
NOTE Confidence: 0.98103917

00:20:41.130 --> 00:20:43.195 DNA repair pathways can influence
NOTE Confidence: 0.98103917

00:20:43.255 --> 00:20:44.695 the development of cancer and

NOTE Confidence: 0.98103917
00:20:44.695 --> 00:20:45.895 how they can be exploited
NOTE Confidence: 0.98103917
00:20:45.895 --> 00:20:46.635 for treatment.
NOTE Confidence: 0.8979699
00:20:47.095 --> 00:20:48.775 And you mentioned the the
NOTE Confidence: 0.8979699
00:20:48.775 --> 00:20:49.355 the BRCA1
NOTE Confidence: 0.9433843
00:20:49.815 --> 00:20:50.475 and BRCA2
NOTE Confidence: 0.83154005
00:20:52.295 --> 00:20:53.435 genes which are linked,
NOTE Confidence: 0.94758743
00:20:55.609 --> 00:20:56.570 to a large extent to
NOTE Confidence: 0.94758743
00:20:56.570 --> 00:20:58.109 breast and ovarian cancers.
NOTE Confidence: 0.94834715
00:21:00.090 --> 00:21:01.450 And defects in those genes
NOTE Confidence: 0.94834715
00:21:01.450 --> 00:21:03.530 lead to a deficiency in
NOTE Confidence: 0.94834715
00:21:03.530 --> 00:21:05.390 a pathway of DNA repair
NOTE Confidence: 0.9829886
00:21:05.945 --> 00:21:07.325 called homologous recombination.
NOTE Confidence: 0.9860671
00:21:08.265 --> 00:21:10.425 We recently discovered that some
NOTE Confidence: 0.9860671
00:21:10.425 --> 00:21:12.105 other genes that are seen
NOTE Confidence: 0.9860671
00:21:12.105 --> 00:21:13.244 mutated in cancers
NOTE Confidence: 0.948239

00:21:13.865 --> 00:21:15.804 that are linked to abnormal
NOTE Confidence: 0.948239

00:21:15.945 --> 00:21:16.445 metabolism
NOTE Confidence: 0.9568783

00:21:17.705 --> 00:21:19.065 also cause a defect in
NOTE Confidence: 0.9568783

00:21:19.065 --> 00:21:20.765 the same DNA repair pathway
NOTE Confidence: 0.9710043

00:21:21.880 --> 00:21:23.260 and we found unexpectedly
NOTE Confidence: 0.9929835

00:21:23.560 --> 00:21:24.940 that they can be exploited
NOTE Confidence: 0.9982009

00:21:25.640 --> 00:21:26.140 with
NOTE Confidence: 0.95027804

00:21:27.160 --> 00:21:27.660 molecularly
NOTE Confidence: 0.9974842

00:21:28.040 --> 00:21:29.580 targeted agents that
NOTE Confidence: 0.9542711

00:21:30.680 --> 00:21:31.740 exploit related
NOTE Confidence: 0.9573806

00:21:32.040 --> 00:21:33.340 DNA repair pathways.
NOTE Confidence: 0.97115487

00:21:34.715 --> 00:21:36.315 And similar to the situation
NOTE Confidence: 0.97115487

00:21:36.315 --> 00:21:37.695 with BRCA1 and BRCA2,
NOTE Confidence: 0.9243045

00:21:38.475 --> 00:21:39.935 these genes include
NOTE Confidence: 0.9272296

00:21:40.635 --> 00:21:42.255 genes with the names IDH1
NOTE Confidence: 0.9272296

00:21:42.475 --> 00:21:44.494 and two, SDH and FH

NOTE Confidence: 0.9272296

00:21:44.715 --> 00:21:45.855 and they're linked to

NOTE Confidence: 0.9188045

00:21:46.570 --> 00:21:49.050 brain tumors, sarcomas, kidney cancers

NOTE Confidence: 0.9188045

00:21:49.050 --> 00:21:49.710 and others.

NOTE Confidence: 0.9895606

00:21:50.170 --> 00:21:50.670 So

NOTE Confidence: 0.94190454

00:21:51.130 --> 00:21:52.490 some of the strategy that

NOTE Confidence: 0.94190454

00:21:52.490 --> 00:21:53.770 we and others have worked

NOTE Confidence: 0.94190454

00:21:53.770 --> 00:21:54.730 on, you can think of

NOTE Confidence: 0.94190454

00:21:54.730 --> 00:21:56.190 it like a traffic pattern

NOTE Confidence: 0.8667809

00:21:56.490 --> 00:21:57.369 since you and I live

NOTE Confidence: 0.8667809

00:21:57.369 --> 00:21:58.590 in Southern Connecticut.

NOTE Confidence: 0.9640354

00:21:59.295 --> 00:22:00.255 If if there's a big

NOTE Confidence: 0.9640354

00:22:00.255 --> 00:22:01.535 crash on I ninety five

NOTE Confidence: 0.9640354

00:22:01.535 --> 00:22:02.735 and you can't get where

NOTE Confidence: 0.9640354

00:22:02.735 --> 00:22:04.095 you're going, you might think

NOTE Confidence: 0.9640354

00:22:04.095 --> 00:22:05.295 of going to the Merritt

NOTE Confidence: 0.9640354

00:22:05.295 --> 00:22:05.795 Parkway,
NOTE Confidence: 0.98119915

00:22:06.255 --> 00:22:07.615 but we're using an agent
NOTE Confidence: 0.98119915

00:22:07.615 --> 00:22:08.975 that blocks the Merritt Parkway,
NOTE Confidence: 0.98119915

00:22:08.975 --> 00:22:10.095 so then you have nowhere
NOTE Confidence: 0.98119915

00:22:10.095 --> 00:22:10.755 to go.
NOTE Confidence: 0.99011177

00:22:11.135 --> 00:22:13.055 And so, we're taking that
NOTE Confidence: 0.99011177

00:22:13.055 --> 00:22:14.490 kind of approach for these,
NOTE Confidence: 0.99011177

00:22:14.970 --> 00:22:16.430 genetically linked cancers.
NOTE Confidence: 0.9977916

00:22:17.050 --> 00:22:19.230 And this is by developing
NOTE Confidence: 0.9977916

00:22:19.369 --> 00:22:19.869 drugs?
NOTE Confidence: 0.9936443

00:22:20.410 --> 00:22:22.010 Yeah. Drugs that target other,
NOTE Confidence: 0.9936443

00:22:22.170 --> 00:22:23.850 DNA repair pathways. So there's
NOTE Confidence: 0.9936443

00:22:23.850 --> 00:22:24.810 a well known class of
NOTE Confidence: 0.9936443

00:22:24.810 --> 00:22:26.270 drugs called PARP inhibitors.
NOTE Confidence: 0.99677753

00:22:26.570 --> 00:22:27.850 We did not develop them,
NOTE Confidence: 0.99677753

00:22:27.850 --> 00:22:29.575 but we're trying to find

NOTE Confidence: 0.99677753

00:22:29.575 --> 00:22:31.034 new uses for them.

NOTE Confidence: 0.9864502

00:22:32.294 --> 00:22:33.494 Another thing that we did

NOTE Confidence: 0.9864502

00:22:33.494 --> 00:22:35.414 was, we found that agents

NOTE Confidence: 0.9864502

00:22:35.414 --> 00:22:36.154 that inhibit

NOTE Confidence: 0.91724485

00:22:36.695 --> 00:22:37.195 angiogenesis,

NOTE Confidence: 0.9469677

00:22:37.734 --> 00:22:39.975 which means the development of

NOTE Confidence: 0.9469677

00:22:39.975 --> 00:22:40.955 new blood vessels,

NOTE Confidence: 0.9182759

00:22:41.960 --> 00:22:43.800 these can lead to reduced

NOTE Confidence: 0.9182759

00:22:43.800 --> 00:22:45.740 oxygen in tumors, a situation

NOTE Confidence: 0.9182759

00:22:45.800 --> 00:22:46.780 known as hypoxia.

NOTE Confidence: 0.9971367

00:22:47.400 --> 00:22:48.140 And that,

NOTE Confidence: 0.93358517

00:22:48.520 --> 00:22:50.600 we found, causes decreased DNA

NOTE Confidence: 0.93358517

00:22:50.600 --> 00:22:51.100 repair,

NOTE Confidence: 0.9993723

00:22:51.480 --> 00:22:52.940 and we can then exploit

NOTE Confidence: 0.9993723

00:22:53.000 --> 00:22:54.440 that situation with some of

NOTE Confidence: 0.9993723

00:22:54.440 --> 00:22:55.720 the agents I just talked
NOTE Confidence: 0.9993723

00:22:55.720 --> 00:22:56.220 about.
NOTE Confidence: 0.99576795

00:22:56.715 --> 00:22:58.155 And is there a role
NOTE Confidence: 0.99576795

00:22:58.155 --> 00:22:59.294 for using radiation
NOTE Confidence: 0.9854145

00:22:59.595 --> 00:23:00.875 in combination with some of
NOTE Confidence: 0.9854145

00:23:00.875 --> 00:23:02.715 these therapies? Yes. For sure.
NOTE Confidence: 0.9854145

00:23:02.715 --> 00:23:03.215 So,
NOTE Confidence: 0.9391286

00:23:03.755 --> 00:23:05.115 some of these DNA repair
NOTE Confidence: 0.9391286

00:23:05.115 --> 00:23:06.655 inhibitors like PARP inhibitors,
NOTE Confidence: 0.98394394

00:23:07.674 --> 00:23:08.875 and others that are in
NOTE Confidence: 0.98394394

00:23:08.875 --> 00:23:10.395 clinical development, there's a number
NOTE Confidence: 0.98394394

00:23:10.395 --> 00:23:11.615 of targeted agents,
NOTE Confidence: 0.96295583

00:23:12.359 --> 00:23:13.559 that we and others are
NOTE Confidence: 0.96295583

00:23:13.559 --> 00:23:14.380 working on,
NOTE Confidence: 0.9942248

00:23:15.160 --> 00:23:17.400 inhibit repair pathways that are
NOTE Confidence: 0.9942248

00:23:17.400 --> 00:23:17.900 important

NOTE Confidence: 0.9926445

00:23:18.680 --> 00:23:20.119 to how the cancer cell

NOTE Confidence: 0.9926445

00:23:20.119 --> 00:23:21.260 tries to fix,

NOTE Confidence: 0.979401

00:23:21.960 --> 00:23:23.320 the type of DNA damage

NOTE Confidence: 0.979401

00:23:23.320 --> 00:23:24.540 the radiation causes.

NOTE Confidence: 0.98928374

00:23:25.174 --> 00:23:26.215 And if I can just

NOTE Confidence: 0.98928374

00:23:26.215 --> 00:23:28.554 explore one other combination that's

NOTE Confidence: 0.98928374

00:23:28.615 --> 00:23:30.635 been talked about recently. So

NOTE Confidence: 0.96235055

00:23:31.095 --> 00:23:31.595 immunotherapy,

NOTE Confidence: 0.99387896

00:23:32.054 --> 00:23:33.195 of course, has become,

NOTE Confidence: 0.99207574

00:23:34.695 --> 00:23:36.315 the treatment of the past

NOTE Confidence: 0.93291515

00:23:36.615 --> 00:23:38.635 decade. It's used in,

NOTE Confidence: 0.9748067

00:23:40.270 --> 00:23:41.970 well over a dozen different

NOTE Confidence: 0.9748067

00:23:42.109 --> 00:23:43.790 tumor types and can be

NOTE Confidence: 0.9748067

00:23:43.790 --> 00:23:44.690 highly effective.

NOTE Confidence: 0.99031883

00:23:45.230 --> 00:23:47.250 But there's some suggestion that

NOTE Confidence: 0.99031883

00:23:47.310 --> 00:23:49.630 radiation could also augment the
NOTE Confidence: 0.99031883

00:23:49.630 --> 00:23:50.609 effect of immunotherapy.
NOTE Confidence: 0.971093

00:23:51.915 --> 00:23:53.515 Yes. I think there's there's
NOTE Confidence: 0.971093

00:23:53.515 --> 00:23:55.515 a lot of, intense study,
NOTE Confidence: 0.971093

00:23:55.515 --> 00:23:57.195 both basic science and in
NOTE Confidence: 0.971093

00:23:57.195 --> 00:23:58.235 the clinic, on how to
NOTE Confidence: 0.971093

00:23:58.235 --> 00:24:00.255 best combine radiation and immunotherapy.
NOTE Confidence: 0.9988304

00:24:01.755 --> 00:24:02.255 Radiation
NOTE Confidence: 0.98252463

00:24:02.715 --> 00:24:03.215 can,
NOTE Confidence: 0.96884054

00:24:03.915 --> 00:24:06.315 elicit an inflamed response in
NOTE Confidence: 0.96884054

00:24:06.315 --> 00:24:06.815 tumors,
NOTE Confidence: 0.9382471

00:24:07.810 --> 00:24:08.310 that,
NOTE Confidence: 0.9959086

00:24:08.690 --> 00:24:09.190 synergizes
NOTE Confidence: 0.99923784

00:24:09.650 --> 00:24:10.770 with the type of immune
NOTE Confidence: 0.99923784

00:24:10.770 --> 00:24:11.750 response that
NOTE Confidence: 0.99108344

00:24:12.050 --> 00:24:14.050 these immune checkpoint inhibitors will

NOTE Confidence: 0.99108344

00:24:14.050 --> 00:24:14.550 provoke.

NOTE Confidence: 0.97284293

00:24:15.730 --> 00:24:17.410 It, it is also thought

NOTE Confidence: 0.97284293

00:24:17.410 --> 00:24:19.170 that radiation can cause the

NOTE Confidence: 0.97284293

00:24:19.170 --> 00:24:21.270 release of tumor antigens and

NOTE Confidence: 0.97284293

00:24:21.525 --> 00:24:22.805 sort of create an in

NOTE Confidence: 0.97284293

00:24:22.805 --> 00:24:24.725 situ tumor vaccine, if you

NOTE Confidence: 0.97284293

00:24:24.725 --> 00:24:25.225 will.

NOTE Confidence: 0.88530135

00:24:26.565 --> 00:24:28.805 So, you know, in general,

NOTE Confidence: 0.88530135

00:24:28.805 --> 00:24:29.765 it's thought that,

NOTE Confidence: 0.998083

00:24:30.165 --> 00:24:32.425 radiation can enhance the effectiveness

NOTE Confidence: 0.998083

00:24:32.645 --> 00:24:33.465 of tumor

NOTE Confidence: 0.94097245

00:24:33.845 --> 00:24:35.780 immune therapy and vice versa,

NOTE Confidence: 0.94097245

00:24:35.840 --> 00:24:37.520 that immune therapy or immune

NOTE Confidence: 0.94097245

00:24:37.520 --> 00:24:39.440 response will enhance the effect

NOTE Confidence: 0.94097245

00:24:39.440 --> 00:24:40.100 of radiation.

NOTE Confidence: 0.99411714

00:24:41.600 --> 00:24:42.740 Have you seen a
NOTE Confidence: 0.93964255

00:24:43.119 --> 00:24:44.580 a change in the
NOTE Confidence: 0.9987531

00:24:45.200 --> 00:24:45.940 type of
NOTE Confidence: 0.9990694

00:24:46.800 --> 00:24:48.740 medical student who goes into
NOTE Confidence: 0.99855477

00:24:49.534 --> 00:24:51.635 radiation oncology today versus
NOTE Confidence: 0.98111117

00:24:52.335 --> 00:24:53.875 twenty or thirty years ago?
NOTE Confidence: 0.98111117

00:24:54.015 --> 00:24:54.975 It would seem to me
NOTE Confidence: 0.98111117

00:24:54.975 --> 00:24:55.775 that a lot of these
NOTE Confidence: 0.98111117

00:24:55.775 --> 00:24:57.294 people must be people who
NOTE Confidence: 0.98111117

00:24:57.294 --> 00:24:57.794 are,
NOTE Confidence: 0.9881319

00:24:59.215 --> 00:25:00.975 interested in physics and interested
NOTE Confidence: 0.9881319

00:25:01.215 --> 00:25:03.054 very interested in science and
NOTE Confidence: 0.9881319

00:25:03.054 --> 00:25:03.554 and
NOTE Confidence: 0.9989204

00:25:03.990 --> 00:25:04.730 perhaps interested
NOTE Confidence: 0.9488303

00:25:05.030 --> 00:25:07.130 in pursuing careers in research.
NOTE Confidence: 0.9730265

00:25:07.830 --> 00:25:08.869 Yes. I think it's always

NOTE Confidence: 0.9730265

00:25:08.869 --> 00:25:10.090 been a research friendly,

NOTE Confidence: 0.9786202

00:25:11.670 --> 00:25:13.350 specialty because there's a lot

NOTE Confidence: 0.9786202

00:25:13.350 --> 00:25:15.590 of basic science, and cellular

NOTE Confidence: 0.9786202

00:25:15.590 --> 00:25:17.030 biology to explore as well

NOTE Confidence: 0.9786202

00:25:17.030 --> 00:25:18.310 as the physics and the

NOTE Confidence: 0.9786202

00:25:18.310 --> 00:25:19.130 more technological

NOTE Confidence: 0.979905

00:25:20.505 --> 00:25:20.744 aspects.

NOTE Confidence: 0.9600152

00:25:21.385 --> 00:25:22.905 I think that, you know,

NOTE Confidence: 0.9600152

00:25:22.905 --> 00:25:24.505 years ago, you know, it

NOTE Confidence: 0.9600152

00:25:24.505 --> 00:25:25.865 was felt, well, maybe people

NOTE Confidence: 0.9600152

00:25:25.865 --> 00:25:26.825 who had a little bit

NOTE Confidence: 0.9600152

00:25:26.825 --> 00:25:28.905 more proclivity for physics might

NOTE Confidence: 0.9600152

00:25:28.905 --> 00:25:30.345 go into the field. But

NOTE Confidence: 0.9600152

00:25:30.345 --> 00:25:31.465 actually, I think the field

NOTE Confidence: 0.9600152

00:25:31.465 --> 00:25:31.965 now

NOTE Confidence: 0.8919977

00:25:32.549 --> 00:25:33.049 attracts,
NOTE Confidence: 0.94563293

00:25:33.509 --> 00:25:35.190 people that like, the,
NOTE Confidence: 0.96933275

00:25:36.149 --> 00:25:37.669 advanced technology that we can
NOTE Confidence: 0.96933275

00:25:37.669 --> 00:25:38.950 bring to bear, the image
NOTE Confidence: 0.96933275

00:25:38.950 --> 00:25:40.090 guidance, the
NOTE Confidence: 0.9260061

00:25:40.630 --> 00:25:42.230 treatment planning that, you know,
NOTE Confidence: 0.9260061

00:25:42.230 --> 00:25:43.210 is very computerized
NOTE Confidence: 0.9704874

00:25:43.590 --> 00:25:44.090 and
NOTE Confidence: 0.6411145

00:25:44.630 --> 00:25:45.130 visual,
NOTE Confidence: 0.89552724

00:25:45.845 --> 00:25:46.345 and,
NOTE Confidence: 0.9894832

00:25:47.045 --> 00:25:48.345 so I think it's expanded
NOTE Confidence: 0.91041905

00:25:48.725 --> 00:25:50.325 the reach of people that
NOTE Confidence: 0.91041905

00:25:50.325 --> 00:25:50.825 are
NOTE Confidence: 0.9566695

00:25:51.205 --> 00:25:52.484 interested in the field. And
NOTE Confidence: 0.9566695

00:25:52.484 --> 00:25:53.285 the other thing is I
NOTE Confidence: 0.9566695

00:25:53.285 --> 00:25:54.405 think people have come to

NOTE Confidence: 0.9566695

00:25:54.405 --> 00:25:55.145 know that

NOTE Confidence: 0.9719112

00:25:55.445 --> 00:25:57.065 we're a very patient oriented

NOTE Confidence: 0.9719112

00:25:57.285 --> 00:25:57.785 specialty,

NOTE Confidence: 0.9644168

00:25:58.830 --> 00:26:00.669 just like your specialty medical

NOTE Confidence: 0.9644168

00:26:00.669 --> 00:26:02.609 oncology. We're very patient facing,

NOTE Confidence: 0.99185985

00:26:03.390 --> 00:26:04.929 and, we have longitudinal

NOTE Confidence: 0.99275947

00:26:05.309 --> 00:26:06.830 relationships with our patients, and

NOTE Confidence: 0.99275947

00:26:06.830 --> 00:26:08.609 I think that that attracts

NOTE Confidence: 0.99275947

00:26:08.669 --> 00:26:10.289 the medical students as well.

NOTE Confidence: 0.8369769

00:26:10.605 --> 00:26:12.045 Longitude and relationships with your

NOTE Confidence: 0.8369769

00:26:12.045 --> 00:26:13.085 patients and,

NOTE Confidence: 0.9728048

00:26:13.565 --> 00:26:15.505 and, of course, close relationships

NOTE Confidence: 0.9728048

00:26:15.645 --> 00:26:17.105 with your colleagues since,

NOTE Confidence: 0.980567

00:26:17.965 --> 00:26:19.165 in the care of patients

NOTE Confidence: 0.980567

00:26:19.165 --> 00:26:20.445 with cancer, we,

NOTE Confidence: 0.98770946

00:26:22.205 --> 00:26:24.125 all work together since it
NOTE Confidence: 0.98770946

00:26:24.125 --> 00:26:24.625 takes
NOTE Confidence: 0.99368507

00:26:25.220 --> 00:26:26.740 far more than any one
NOTE Confidence: 0.99368507

00:26:26.740 --> 00:26:27.240 discipline.
NOTE Confidence: 0.9465303

00:26:28.420 --> 00:26:29.560 And as we,
NOTE Confidence: 0.99882066

00:26:30.420 --> 00:26:31.160 wrap up,
NOTE Confidence: 0.9998301

00:26:31.540 --> 00:26:32.280 can you
NOTE Confidence: 0.99921

00:26:33.060 --> 00:26:35.400 speculate about where radiation
NOTE Confidence: 0.9994464

00:26:35.780 --> 00:26:36.280 oncology
NOTE Confidence: 0.999265

00:26:36.580 --> 00:26:38.420 is going over the course
NOTE Confidence: 0.999265

00:26:38.420 --> 00:26:39.320 of the next
NOTE Confidence: 0.9489286

00:26:39.635 --> 00:26:41.015 ten or twenty years?
NOTE Confidence: 0.97161585

00:26:41.395 --> 00:26:42.595 What do we what what
NOTE Confidence: 0.97161585

00:26:42.595 --> 00:26:44.135 should we be looking for?
NOTE Confidence: 0.97161585

00:26:44.355 --> 00:26:45.315 Well, I think that we're
NOTE Confidence: 0.97161585

00:26:45.315 --> 00:26:46.595 gonna see a a greater

NOTE Confidence: 0.97161585
00:26:46.595 --> 00:26:47.575 ability to
NOTE Confidence: 0.9937108
00:26:48.035 --> 00:26:49.715 achieve real time adjustments in
NOTE Confidence: 0.9937108
00:26:49.715 --> 00:26:50.375 the treatment,
NOTE Confidence: 0.98063123
00:26:50.994 --> 00:26:52.355 using some of these onboard
NOTE Confidence: 0.98063123
00:26:52.355 --> 00:26:54.535 imaging technologies. And as the
NOTE Confidence: 0.9977882
00:26:55.280 --> 00:26:55.780 software
NOTE Confidence: 0.99854094
00:26:56.480 --> 00:26:57.700 and hardware improves
NOTE Confidence: 0.9644815
00:26:58.240 --> 00:26:59.919 and we can incorporate things
NOTE Confidence: 0.9644815
00:26:59.919 --> 00:27:02.419 like artificial intelligence to identify
NOTE Confidence: 0.94083
00:27:02.880 --> 00:27:04.480 the tumor targets, track how
NOTE Confidence: 0.94083
00:27:04.480 --> 00:27:06.580 they move and adjust radiation
NOTE Confidence: 0.94083
00:27:06.640 --> 00:27:07.140 treatments.
NOTE Confidence: 0.93038464
00:27:07.815 --> 00:27:09.255 That's going to allow even
NOTE Confidence: 0.93038464
00:27:09.255 --> 00:27:10.075 more precise
NOTE Confidence: 0.9921966
00:27:10.375 --> 00:27:11.034 and tailored
NOTE Confidence: 0.9928529

00:27:11.734 --> 00:27:13.434 radiation therapy for patients.

NOTE Confidence: 0.95482516

00:27:13.815 --> 00:27:14.855 I think also we're going

NOTE Confidence: 0.95482516

00:27:14.855 --> 00:27:15.914 to see more individualized

NOTE Confidence: 0.9754847

00:27:16.215 --> 00:27:17.895 patient treatments based on clinical

NOTE Confidence: 0.9754847

00:27:17.895 --> 00:27:19.195 and genetic characteristics

NOTE Confidence: 0.9787068

00:27:20.250 --> 00:27:22.010 And, like we were alluding

NOTE Confidence: 0.9787068

00:27:22.010 --> 00:27:22.670 to before,

NOTE Confidence: 0.9512168

00:27:23.290 --> 00:27:24.330 I see the next five

NOTE Confidence: 0.9512168

00:27:24.330 --> 00:27:25.150 or ten years,

NOTE Confidence: 0.99292415

00:27:25.850 --> 00:27:26.970 that we will be able

NOTE Confidence: 0.99292415

00:27:26.970 --> 00:27:28.830 to deploy new targeted biological

NOTE Confidence: 0.99292415

00:27:29.050 --> 00:27:30.890 agents that sensitize tumors to

NOTE Confidence: 0.99292415

00:27:30.890 --> 00:27:31.390 radiation

NOTE Confidence: 0.98008096

00:27:32.425 --> 00:27:32.925 without

NOTE Confidence: 0.9312142

00:27:33.545 --> 00:27:35.565 sensitizing healthy tissues. And,

NOTE Confidence: 0.9805732

00:27:36.105 --> 00:27:37.465 you know, for example, we're

NOTE Confidence: 0.9805732

00:27:37.465 --> 00:27:38.425 working in the lab to

NOTE Confidence: 0.9805732

00:27:38.425 --> 00:27:39.865 develop a class of peptide

NOTE Confidence: 0.9805732

00:27:39.865 --> 00:27:41.785 drug conjugates that does just

NOTE Confidence: 0.9805732

00:27:41.785 --> 00:27:42.285 that.

NOTE Confidence: 0.95783776

00:27:43.225 --> 00:27:44.905 And the preclinical models look

NOTE Confidence: 0.95783776

00:27:44.905 --> 00:27:46.845 encouraging, so hopefully that will

NOTE Confidence: 0.9908915

00:27:47.179 --> 00:27:48.380 eventually make its way to

NOTE Confidence: 0.9908915

00:27:48.380 --> 00:27:50.140 the clinic. And, you know,

NOTE Confidence: 0.9908915

00:27:50.140 --> 00:27:51.020 not to set up a

NOTE Confidence: 0.9908915

00:27:51.020 --> 00:27:52.700 competition with surgery, but do

NOTE Confidence: 0.9908915

00:27:52.700 --> 00:27:53.760 you think these changes

NOTE Confidence: 0.9995857

00:27:54.299 --> 00:27:56.400 will lead to fewer surgical

NOTE Confidence: 0.9995857

00:27:56.460 --> 00:27:56.960 procedures

NOTE Confidence: 0.9960714

00:27:57.260 --> 00:27:58.400 and more radiation?

NOTE Confidence: 0.9936075

00:27:59.065 --> 00:28:00.265 Well, I think it's it

NOTE Confidence: 0.9936075

00:28:00.265 --> 00:28:02.105 may change the balance for
NOTE Confidence: 0.9936075

00:28:02.105 --> 00:28:03.865 certain tumors. I think I've
NOTE Confidence: 0.9936075

00:28:03.865 --> 00:28:05.625 seen that the pendulums has
NOTE Confidence: 0.9936075

00:28:05.625 --> 00:28:06.765 swung back and forth,
NOTE Confidence: 0.9587783

00:28:08.345 --> 00:28:10.345 for different, types of tumors
NOTE Confidence: 0.9587783

00:28:10.345 --> 00:28:10.665 where,
NOTE Confidence: 0.8899609

00:28:11.790 --> 00:28:13.250 you know, radiation approaches,
NOTE Confidence: 0.96538514

00:28:14.350 --> 00:28:15.630 are more favored and then
NOTE Confidence: 0.96538514

00:28:15.630 --> 00:28:17.070 surgical. It really it really
NOTE Confidence: 0.96538514

00:28:17.070 --> 00:28:18.450 depends. I mean, the surgeons
NOTE Confidence: 0.98142624

00:28:18.910 --> 00:28:19.869 have been very good to
NOTE Confidence: 0.98142624

00:28:19.869 --> 00:28:21.869 advance their technology to robotic
NOTE Confidence: 0.98142624

00:28:21.869 --> 00:28:24.190 surgeries and minimally invasive surgeries.
NOTE Confidence: 0.98142624

00:28:24.190 --> 00:28:25.230 So I think it's all
NOTE Confidence: 0.98142624

00:28:25.230 --> 00:28:26.030 to the good for the
NOTE Confidence: 0.98142624

00:28:26.030 --> 00:28:27.794 patients, and we'll just have

NOTE Confidence: 0.98142624

00:28:27.794 --> 00:28:29.794 more choices for figuring out

NOTE Confidence: 0.98142624

00:28:29.794 --> 00:28:30.695 the best treatments.

NOTE Confidence: 0.95241964

00:28:31.315 --> 00:28:32.674 Doctor Peter Glaser is the

NOTE Confidence: 0.95241964

00:28:32.674 --> 00:28:34.195 Robert e Hunter Professor of

NOTE Confidence: 0.95241964

00:28:34.195 --> 00:28:36.355 Therapeutic Radiology and Professor of

NOTE Confidence: 0.95241964

00:28:36.355 --> 00:28:37.955 Genetics and Chair of the

NOTE Confidence: 0.95241964

00:28:37.955 --> 00:28:39.875 Department of Therapeutic Radiology at

NOTE Confidence: 0.95241964

00:28:39.875 --> 00:28:41.255 the Yale School of Medicine.

NOTE Confidence: 0.99032795

00:28:41.730 --> 00:28:43.010 If you have questions, the

NOTE Confidence: 0.99032795

00:28:43.010 --> 00:28:43.990 address is canceranswers

NOTE Confidence: 0.945039

00:28:44.370 --> 00:28:46.050 at yale dot edu, and

NOTE Confidence: 0.945039

00:28:46.050 --> 00:28:47.410 past editions of the program

NOTE Confidence: 0.945039

00:28:47.410 --> 00:28:48.929 are available in audio and

NOTE Confidence: 0.945039

00:28:48.929 --> 00:28:50.150 written form at yalecancercenter

NOTE Confidence: 0.99962664

00:28:50.690 --> 00:28:52.210 dot org. We hope you'll

NOTE Confidence: 0.99962664

00:28:52.210 --> 00:28:53.170 join us next time to

NOTE Confidence: 0.99962664

00:28:53.170 --> 00:28:54.130 learn more about the fight

NOTE Confidence: 0.99962664

00:28:54.130 --> 00:28:54.950 against cancer.

NOTE Confidence: 0.97473866

00:28:55.405 --> 00:28:57.085 Funding for Yale Cancer Answers

NOTE Confidence: 0.97473866

00:28:57.085 --> 00:28:58.685 is provided by Smilow Cancer

NOTE Confidence: 0.97473866

00:28:58.685 --> 00:28:59.185 Hospital.